
The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



Onan

Parts Manual

DDA GenSet



944-0222 SPEC D 7-81 Replaces 11-79 (Spec D) Printed in U.S.A.

Redistribution or publication of this document by any means, is strictly prohibited.

GENERAL INFORMATION


INSTRUCTIONS FOR ORDERING REPAIR PARTS

For parts or service, contact the dealer from whom you purchased this equipment or refer to your Nearest Authorized Onan Parts and Service Center.

To avoid errors or delay in filling your parts order, please furnish all information requested.

Always refer to the nameplate on your unit.

1. Always give the MODEL, SPEC NO. and SERIAL NO.



For handy reference, insert "YOUR" nameplate information in the spaces above.

- 2. Do not order by reference number; always use part number and description.
- 3. Give the part number, description and quantity needed of each item. If an older part cannot be identified, return the part prepaid to your dealer or nearest Onan Parts and Service Center. Print your name and address plainly on the package. Write a letter to the same address stating the reason for returning the part.
- 4. State definite shipping instructions. Any claim for loss or damage to your unit in transit should be filed promptly against the transportation company making the delivery. Shipments are complete unless the packing list indicates items are back ordered.

Prices are purposely omitted from this Parts Catalog due to the confusion resulting from fluctuating costs, import duties, sales taxes, exchange rates, etc.

For current parts prices, consult your Onan Dealer, Distributor or Parts and Service Center.

"En esta lista de partes los precios se omiten de proposito, ya que bastante confusion resulto de fluctuaciones de los precios, derechos aduanales, impuestos de venta, cambios extrajeros, etc."

Consiga los precios vigentes de su distribuidor de productos "ONAN."



Std. #36



INDEX

LC .	CATION
GENERAL INFORMATION	A2
SET DATA TABLE	A4
REPLACEMENT ENGINE	A5
EQUIPMENT PARTS SECTION	
AIR CLEANER	A6
ALTERNATOR	A7
CHASSIS	B10
CONTROL, ENGINE	B2
CONTROL GENERATOR	B4
COOLING SYSTEM (WITH RADIATOR)	A12
CURRENT TRANSFORMER ASSEMBLY	B8
ENGINE PARTS, MISCELLANEOUS (LEFT SIDE)	A8
Engine coolant temperature sender	
High coolant temperature switch - shutdown	
Low oil pressure switch	
Oil drain hardware	
Oil pressure sender	
Tachometer drive and sender	
Wiring Harness - Engine	A 10
ENGINE PARTS, MISCELLANEOUS (RIGHT SIDE)	A10
Battery and starter cables	
Fuel lines	
Fuel pressure sender High coolant temperature switch - Alarm	
Low engine temperature switch	
Oil temperature sender	
Starter	
GENERATOR ASSEMBLY	B6
HOUSING CONTROL	A13
ROTOR, EXCITER	B9
OPTIONAL EQUIPMENT SECTION	
CIRCUIT BREAKER	C6
CONTROL FNGINE (WITH FIVE FAULT LIGHTS)	<i></i> C2
CONTROL FUGINE (WITH MECHANICAL GAUGES)	.,, E12
FILTER FUEL	D14
FILTER VOLTAGE REGULATOR	E14
COOLING SYSTEM (CITY WATER)	D10
COOLING SYSTEM (CITY WATER WITH WATER COOLED MANIFOLD)	D12
COOLING SYSTEM (WITH HEAT EXCHANGER)	D4
COOLING SYSTEM (WITH CIRCULAR STANDPIPE)	D6
COOLING SYSTEM (WITH SQUARE STANDPIPE)	D8
GOVERNOR	F1
HEATER, CONTROL	
HEATER, ENGINE COOLANT	DZ
HEATER, GENERATOR	Co
HOUSING, SET MANIFOLD, EXHAUST - LIQUID COOLED	UIU
MUFFLER, EXHAUST - HOUSED SETS	F0
OUTPUT BOX ASSEMBLY - HOUSED SETS	
SWITCH, DUAL PHASE - UNHOUSED SETS	C12
SWITCH, DUAL PHASE - HOUSED SETS	C13
SWITCH - LOW COOLANT LEVEL	F2
TACHOMETER	C2
TANK, FUEL - 20 GALS (HOUSED SET MOUNTED)	E4
TANK FUEL RESERVOIR (HOUSED SETS)	E6
TANK FUEL RESERVOIR (UNHOUSED SETS)	. <i></i> E 8
TANK, FUEL RESERVOIR (OVERHEAD/UNDERGROUND APPLICATIONS)	E10
VERNIER THROTTLE	E13
WATTMETER	C8



This parts catalog applies to the standard generator sets listed below. Any engine parts modified or added by Onan will be listed in this catalog and have been assigned Onan part numbers for identification. These modified or added parts supersede similar parts listed in the Engine Manufacturer's manuals. The illustrations are arranged in groups of related items, and each part or assembly is identified by a reference number. All parts illustrated are typical, and unless otherwise mentioned, parts are interchangeable. These typical illustrations are subject to change and reflect only the latest replacement parts arrangement. The Right and Left generator set sides are determined by facing the front end of the engine.

SET DATA TABLE

MODEL IDENTIFICATION	RATING	MODEL IDENTIFICATION	RATING
25.0 DDA - * / # £	25,000 WATTS	30.0 DDA - * / # £	30,000 WATTS

ELECTRICAL DATA TABLE

* VOLTAGE CODES	VOLTS	HERTZ	WIRE	PHASE	NOTES
3	120/240	60	3	1	
6D	240/480	60	4	3	
7	220/380	60	4	3	
.9X	347/600	60	.4	3 .	
15	120/240,	60	12	1 ' .	+
15	120/208,	60	12	3	•
1	120/240,		!		
	127/220,	· -			n a element
	139/240,		[,	
•	240/416,				
	254/440,		· .		l the Sales At E.
	277/480		f		
515	110/220,	50	. 12	1	+
	115/230				
515	110/290,	50	12	3	. •
	110/120,			•	
	115/200,				
	115/230,				
	120/208				
•	127/220,				
	220/380,		ĺ		· .
	230/400				
	240/416		2.5		
	254/440,				
. 15R50	@ -	60	12	3	@+
L	<u> </u>				

- Voltage codes follow model letters designations.
- # Specification number; number 1 is standard, all others indicate variations.
- £ Specification letter; letter advances (A to B, B to C, etc.) with major manufacturing changes.
- + These generators are reconnectible, refer to Operator's manual for wiring data.
- @ These are Penn State Sets; voltage codes same as 15; special parts are identified in the Parts manual when applicable.

NOTICE!

ITEMS REFERENCED AS **OPTIONAL** INDICATE PART IS FACTORY INSTALLED AND MAY NOT BE APPLICABLE TO ALL MODELS. FOR FIELD CONVERSIONS ADDITIONAL PARTS ARE USUALLY REQUIRED.



REPLACEMENT ENGINE

ONAN PART NO.


100-1265

*Engine, Replacement

Includes: Complete Cylinder Block, Fuel Pump, Fuel Filter, Oil Filter, Governor, Fan Blades (Pusher Type), Water Pump, Oil Pan, Oil Fill, Exhaust Manifold, Flywheel Housing, Starter Adapter, Fan Belt, Alternator Drive Belt and Flywheel.

Excludes: Alternator, Temperature Sender, Oil Pressure Sender, Starter, Air Cleaner, and Radiator.

NOTE: This replacement engine is for Onan's Standard Spec 1 generator sets, for all other refer to the factor for replacement information.




For handy reference, insert "YOUR" nameplate information in the spaces above.

ENGINE REPLACEMENT PARTS

All engine replacement parts must be ordered from the engine manufacturer, except those modified or added by Onan. When ordering engine parts, refer to the manufacturer's nameplate and supply the Model, Spec, Serial numbers and other available information. Refer to the engine manufacturer's manuals for your nearest authorized distributor or parts center; or contact the Onan distributor from whom you purchased this set for assistance in ordering replacement parts.






REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	503-0465	2	Clamp, Hose
2	503-0482	1	Hose, Rubber (2-1/4" ID x 3" Lg)
3	865-0020	1	Nut, Wing (1/4-20)
4	140-1083	1	Air Cleaner Assembly (Includes Element)
5	140-1089	1	Element, Air Cleaner



ALTERNATOR




XES1173

REF. NO.	PART NO.	QTY. USED	PART Description
1	800-0024	1	Screw, Cap - Hex Head (5/16-18 x 1/2")
2	850-0045	1	Washer Lock - Spring (5/16")
3	191-0725	1	Guard, Belt
4	800-0030	1	Screw, Cap - Hex Head (5/16-18 x 1-1/4")
5	526-0115	2	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)
6	850-0045	1	Washer, Lock - Spring (5/16")
7	862-0015	1	Nut, Hex (5/16-18)
8	800-0058	1	Screw, Cap - Hex Head (3/8-16 x 3")
9	526-0035	2	Washer, Flat (17/32" ID x 7/8" OD x 1/8" Thk)
10	850-0050	1	Washer, Lock - Spring (3/8")
11	862-0003	1	Nut, Hex (3/8-16)
12	232-2183	1	Spacer, Stepped
13	312-0201	1	Capacitor
14	191-1099	1	Pulley
15	191-1388	1	Alternator (Includes Regulator and Capacitor)
16	191-1390	1	Regulator, Voltage - Part of Alternator (Includes Capacitor)



A7

MISCELLANEOUS ENGINE PARTS - LEFT SIDE






MISCELLANEOUS ENGINE PARTS — LEFT SIDE

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	WIRING HA	RNESS - E	ENGINE	16	309-0169	1	Switch, Pressure - Oil
•	338-0771	1	Standard Special	17	505-0058	1	Tee, Pipe (1/8" NPT) - (Used In Some Installations)
2 3	503-0197 503-0888	1	Clamp, Hose Hose, Rubber (3/4" ID x 1" OD	18 19	505-0763 505-0098	1 1	†Cross, Pipe (1/8" NPT) Nipple, Pipe-Close (1/8" NPT x
4 5	505-0185 504-0011	. 1 · 1	x 17" Lg) Nipple, Pipe - Half Valve, Cock	20	193-0246	1	3/4") Sender, Temperature - Engine Coolant
6	505-0100	1	Nipple, Pipe - Close (1/2" NPT x 1-1/8")	21	505-0131	1	Bushing, Reducer - Hex (3/4" NPT x 3/8" NPT)
7	505-0050	1	Elbow, Pipe - Street, 90 DEG (1/2" NPT)	22	309-0179	1	†Switch, Thermostatic - High Coolant Temperature -
8	503-0197	1	Clamp, Hose				Shutdown
9	503-0889	1	Hose, Rubber (3/4" ID x 1" OD x 24" Lg)	23	505-0117	1	Bushing, Reducer - Flush, Brass (1/2" NPT x 3/8" NPT)
10	148-0274	2	Bracket, Support - Hose	* NO	TF: For Speci	ial Applic	ations Use Standard Wiring Harness
11	302-0750	1	†Sender, Tachometer				as required for optional sensors,
12	302-0967	1	† Tang, Tachometer		tches per Ger		
13	309-0064	1	†Switch, Pressure - Oil		•		• •
14	505-0057	1	Plug, Pipe (1/8" NPT) - (Used When No Oil Switch)		tional items, atrol Panel.	used with	n fault lights or gauges on Engine
15	193-0244	1	Sender, Pressure - Oil				



MISCELLANEOUS ENGINE PARTS - RIGHT SIDE



XM1229




MISCELLANEOUS ENGINE PARTS — RIGHT SIDE

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO	QTY. USED	PART DESCRIPTION
1			ARE FOR STARTER & CABLES	10	502-0619	1	†Adapter, Pipe (1/8-27" NPT Male x 1/2-20 Male)
	800-0051	3	Screw, Cap - Hex Head (3/8-16 x 1-1/4")	11	193-0302	1	†Sender, Pressure - Fuel
	850-0050	3	Washer, Lock - Spring (3/8")	12	502-0058	1	†Tee, Pipe - Street
	856-0010	. 1	Washer, Lock - External/Internal Tooth (3/8")	13	821-0029	1	Screw, Self-locking - Hex Washer Head (3/8-16 x 3/4")
	800-0090	1	Screw, Cap - Hex Head (1/2-13 x 1")	14	309-0269	1	†Switch, Thermostatic - Low Engine Temperature
	856-0013	1	Washer, Lock - External/Internal Tooth (1/2")	15	309-0178	1	†Switch, Thermostatic - High Coolant Temperature - Alarm
2	332-1292	1	Terminal Board	16	505-0117	1	†Bushing, Reducer - Flush, Brass
3	416-0530	1	Cable, Battery - Negative (16" Lg)				(1/2" NPT x 3/8" NPT)
4	416-0531	1	Cable, Battery - Positive (24" Lg)	17	134-1437	1	Spring, Holddown - Shutter Pivot
5	416-0446	1	Cable, Battery - Jumper	t - On	tional Items.	used wit	h fault lights or gauges on Engine
6	191-1117	1	Starter, Electrical - 12 Volt		ntrol Panel.		
7	193-0249	1	†Sender, Temperature - Oil		na or r anon		
8	501-0395	1	†Line, Fuel - Flexible				
9	502-0688	1	†Elbow, Pipe - 90 DEG (1/8-27"				

NPT Male x 1/2-20 Male)




COOLING SYSTEM (WITH RADIATOR)



REF. NO.	PART NO	QTY. USED	PART DESCRIPTION
. 1	503-0365	4 .	Clamp Hose
2	503-0727	. 1	Hose, Radiator - Upper
3	503-0635	1	Hose, Radiator - Lower
4	815-0181	8	Screw, Tapping - Hex Head (#10-32 x 1/2")
5	130-0934	1	Guard, Fan - Right Side
6	130-0935	1	Guard, Fan - Left Side
7	504-0028.		Cock, Drain
8	821-0014	6	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
9	870-0113	6	Nut, Hex with Retaining Clip (5/16-18)
10	130-0815	1 11	Radiator (Includes Cap)
11	130-0449	1	Cap, Pressure
12	815-0181	10	Screw, Tapping - Hex Head (#10-32 x 1/2")
13	405-1054	1	Flange, Air Duct
14	821-0014	8	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
15	405-1811	1	Panel, Front
16	800-0050	4	Screw, Cap - Hex Head (3/8-16 x 1" Lg)
17	850-0050	. 4	Washer, Lock - Spring (3/8")
18	130-0941	· 1 .	Fan, Cooling - Engine



CONTROL HOUSING




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	821-0010	8	Screw, Self-locking - Hex	8	856-0006	1	Washer, Lock - EIT (1/4")
			Washer Head (1/4-20 x 1/2")	9	526-0018	5	Washer, Flat (17/64" ID x
2	234-0370	1	Grill, Air - Generator Inlet				5/8" OD x 1/16" Thk)
3	815-0350	18	Screw, Tapping - Hex Washer	10	870-0212	6	Nut, Hex (1/4-20)
			Head (#10-32 x 3/8")	11	301-3155	1	Housing, Control Box
4	301-3156	3	Panel, Access	12	508-0203	1	Bushing, Cable - Nylon
5	821-0010	4	Screw, Self-locking - Hex	13	821-0010	1	Screw, Self-locking - Hex
			Washer Head (1/4-20 x 1/2")				Washer Head (1/4-20 x 1/2")
6	234-0361	1	Wrapper, End Bell	14	821-0014	8	Screw, Self-locking - Hex
7	821-0018	6	Screw, Self-locking - Hex				Washer Head (5/16-18 x 1/2")
			Washer Head (1/4-20 x 5/8")	15	301-3154	1	Saddle, Control Box

944-0222 (JULY 1981)



ENGINE CONTROL WITH ONE FAULT LIGHT



B2



944-0222 (JULY 1981)

ENGINE CONTROL WITH ONE FAULT LIGHT

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART Description
1	322-0004	1	Lamp Incandescent (12 VDC)	26	860-0006	1	Nut, Hex (#6-32)
2	322-0004	i	Lampholder	27	853-0003	1	Washer, Lock - ET (#6)
3	308-0002	i	Switch, Toggle (SPST)	28	356-0072	i	Capacitor, Fixed Electrolytic
4	307-1157	3	Spring, Holddown - Relay	20	000 0072	•	(4000 MFD, 30 VDC)
5	RELAY (12)	_	opinig, riologoviii riela)	29	812-0063	2	Screw, Machine - Round Head
Ü	307-1058	1	(Ignition)	20	012 0000	_	(#6-32 x 1/2")
	307-1058	ì	(Start Disconnect)	30	853-0003	2	Washer, Lock - ET (#6)
	307-1061	i	(Starter Protection)	31	356-0070	1	Clamp, Capacitor Mounting
7	193-0243	1	Gauge - Oil Pressure (12 VDC)	32	870-0053	ì	Nut, Hex (#10-32)
8	193-0245	i	Gauge - Water Temperature	33	850-0030	1	Washer, Lock - Spring (#10)
	, , , , , , , , , , , , , , , , , , , ,		(12 VDC)	34	332-0051	1	Сіатр, Loop
9	302-0061	1	Ammeter	35	HARNESS.	WIRING -	ENGINE CONTROL
10	302-0749	1	£Tachometer - Electrical		338-1065	1	Includes parts marked f
11	193-0248	1	£Gauge - Oil Temperature		ATTACHING	G HARDW	ARE FOR WIRING HARNESS
			(12 VDG)		812-0061	- 4	Screw, Machine - Round Head
12	SWITCH, TO	OGGLE - S	SELECTOR				(#6-32 x 3/8")
	308-0138	1	Standard & Cycle Cranking Controls		812-0066	6	Screw, Machine - Round Head (#6-32 x 3/4")
	309-0327	1	Penn State Controls		853-0003	14	Washer, Lock - ET (#6)
13	*LIGHT, IND	ICATOR (Lens Color & Legend Listed Below)		860-0006	10	Nut, Hex (#6-32)
	322-0128	1 `	Red - Fault - 14 VDC	36	332-1043	1	†Jumper, Terminal
14	322-0136	1	*Light, Indicator - 14 VDC (Red	37	332-0795	1	†Block, Terminal - 16 Place
			Lens - No Legend)	38	332-0537	1	†Block, Terminal - 4 Place
15	518-0374	4	Fastener, Snap-In (Printed	39	323-0765	2	†Socket, Relay - 11 Place
			Circuit Boards)	40	323-0764	1	†Socket, Relay - 8 Place
16			OARD ASSEMBLY (See Separate	41	332-1271	2	†Connector, Electrical - PC BD
	Parts Catalo	og #900-02	34 for Components)	42	332-1241	1	Strip, Marker - Terminal
	300-0733	1	Standard Cranker (12 VDC)	43	332-1239	1	Strip, Marker - Terminal
	300-0714	1	Cycle Cranker (12 VDC)			ERMINAL	ASSEMBLY (Includes parts
17			OARD ASSEMBLY (See Separate		marked #)		
			34 for Components)	44	871-0010	2	#Nut, Hex - Brass (#10-32)
	300-0 6 79	1	Engine Control Monitor -	45	850-0030	1	#Washer, Lock - Spring (#10)
			Standard	46	526-0205	2	#Washer, Flat - Brass (13/64" ID
	300-0730	1	Engine Control Monitor -				x 7/16" OD x 1/16" Thk)
			Penn State	47	853-0008	1	#Washer, Lock - ET (#10)
18	332-1276	4	Plug, Keying - PC Board	48	856-0003	1	#Washer, Lock - EIT (#10)
20	813-0098	2	Screw, Machine - Round Head (#10-32 x 3/8")	49	815-0203	1	#Screw, Machine - Round Head, Brass (#10-32 x 7/8")
21	850-0030	2	Washer, Lock - Spring (#10)	50	815-0026	5	Screw, Machine - Truss Head
22	526-0009	2	Washer, Flat (7/32" ID x 1/2" OD		~~~ ~~~	_	(#10-32 x 3/8")
-	050 0000	^	x 1/16" Thk)	51	870-0053	1	Nut, Hex (#10-32)
23	856-0003	2	Washer, Lock - EIT (#10)	52	850-0030	1 1	Washer, Lock - Spring (#10)
24	307-1031	1	Relay, Solenoid - Start (12 VDC)	53 54	856-0003 PANEL, CO	-	Washer, Lock - EIT (#10)
25	812-0061	1	Screw, Machine - Round Head	54	301-3165	1	With Three Gauge Mtg. Holes
			(#6-32 x 3/8")		301-3165	1	With Four Gauge Mtg. Holes
					301-3396	1	With Five Gauge Mtg. Holes
				55	301-3253	i	Bracket, Mounting Engine
				00	001 0200	•	Control




^{* -} NOTE: For lamp replacement order 322-0136 remove and discard plain red lens, install lens with legend from burned out light — lights snap in and out of panel.

^{£ -} Optional items used with Engine Mounted Senders.

^{† -} Parts includes in Wiring Harness

^{# -} Parts includes in Ground Terminal Assembly

CONTROL - GENERATOR



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	307-1157	1	Spring, Holddown, Relay - Code 15R, 515R	4	VOLTMET	ER (Selectia	s Required) SINGLE SCALE
2	307-1061	1	Relay Code 15R, 515R	1 2002	302-0421	1	0-300 Volt
3	AMMETER	(Select as I			302-0422 302-0612	1	0-600 Volt 0-500 Volt
	302-0406	1	0-50 Amp	-3	302-0779	1	0-750 Volt
	302-0408	1	0-75 Amp			•	DUAL SCALE
	302-0410	1	0-100 Amp		302-0718	1 .	0-300, 0-600 Volt
	302-0411	1	0-200 Amp	5	METER, FR	REQUENCY	(Select as Required)
	302-0412	1	0-250 Amp		•	•	REED TYPE
	302-0413	1	0-300 Amp		302-0213	1	115 VAC, 60 Hz
	302-0605	1	0-400 Amp		302-0221	1	230 VAC, 60 Hz
	•		DUAL SCALE		302-0234	· 1	115 VAC, 50 Hz
	302-0719	1	0-75, 0-150 Amp		302-0256	1	230 VAC, 50 Hz
	302-0720	1	0-100, 0-200 Amp				POINTER TYPE
_	302-0721	1	0-150, 0-300 Amp		302-0809	1	120 VAC, 60 Hz
	302-0722	. 1	0-200, 0-400 Amp		302-0810	1	208 VAC, 60 Hz
	302-0723	1 '	0-250, 0-500 Amp		302-0811	-1	240 VAC, 60 Hz
	302-0724	1	0-375, 0-750 Amp				



944-0222 (JULY 1981)


CONTROL - GENERATOR

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
6	302-0466	1	ZING (Select as Required) 60 Hz	26	332-1242	1	ect as Required) 16 Place
7	302-0469 'LIGHT, INDIC Listed Below)	1 ATOR - 1	50 Hz 125 VAC (Lens Color & Legend	27	332-1248 812-0065	1 4	12 Place Screw, Machine - Round Head (#6-32 x 5/8")
	322-0130	1	Red - Lower Scale	28	853-0003	4	Washer, Lock - ET (#6)
	322-0131		Red - Upper Scale	29	332-1956	1	£Regulator, Voltage
8	322-0178	1	*Light, Indicator - 125 VAC	30	321-0204	2 1	Fuse, Cartridge (1/4 Amp) Transformer, Voltage
9	320-0307	1	(Amber Len - No Legend) Lock - Circuit Breaker Handle	31	315-0431		FOR TRANSFORMER
. 9	320-0307	ı	(Penn State Sets)		812-0061	2	Screw, Machine - Round Head
	ATTACHING	HARDWA	ARE FOR LOCK				(#6-32 x 3/8")
	815-0203	1	Screw, Machine - Round Head		853-0003	2	Washer, Lock - ET (#6)
	001.0010	4	(#10-32 x 7/8")	32	305-0675	1 C DARTS I	Rectifier Bridge FOR RECTIFIER
	854-0010 871-0010	1	Washer, Lock - IT (#10) Nut, Hex (#10-32)		812-0070	2	Screw, Machine - Round Head
10	320-0431	i	Circuit Breaker		012 0070	-	(#6-32 x 1-1/4")
			ARE FOR CIRCUIT BREAKER		850-0020	2	Washer, Lock - Spring (#6)
	812-0061	2	Screw, Machine - Round Head	33	315-0384	1	Reactor
			(#6-32 x 3/8")				FOR REACTOR
	850-0020	2	Washer, Lock - Spring (#6)		812-0061	2	Screw, Machine - Round Head (#6-32 x 3/8")
	815-0203	1	Screw, Machine - Round Head, Brass (#10-32 x 7/8")		853-0003	2	Washer, Lock - ET (#6)
	871-0010	1	Nut, Hex - Brass (#10-32)	34	406-0332	2	Receptacle, Turnbutton
	853-0008	1	Washer, Lock - ET (#10)				Fastener
	526-0049	1	Washer, Flat - Brass (13/64" ID	35	508-0001	4	Grommet, Rubber
			x 7/16" OD x 1/32" Thk)	36	800-0045	4	Screw, Cap - Hex Head
11	406-0334	2	Clip, Retaining - Turnbutton Fastener	37	850-0045	4	(5/16-18 x β/8") Washer, Lock - Spring (5/16")
12	406-0333	2	Stud, Turnbutton Fastener	38	402-0070	4	Dampener, Vibration
13	517-0131	1	Plug, Plastic	39	815-0026	3	Screw, Machine - Truss Head
14	303-0076	1	Knob, Pointer				(#10-32 x 3/8")
15	308-0284	1	Switch, Selector	40	PANEL, CO	NTROL	O I MOUL AND DO IT
16	303-0032	1	Knob		201 2000	4	Sets Without Meter Panel Code 3R
17 18	303-0170 301-3244	1	Rheostat (35K Ohms, 25 Watt) Bracket, Mounting, Relay -		301-3822 301-3821	1 1	Code 9XR, 6DR, 7R
10	301-0244	,	Code 15R, 15R50, 515R		301-3274	1	Code 15R, 515R
19	870-0053	1	Nut, Hex (#10-32)				Sets With Meter Panel
20	850-0030	1	Washer, Lock - Spring (#10)		301-3169	1	Code 3R
21	332-0051	1	Clamp, Loop		301-3342	1	Code 9XR, 6DR, 7R
22	HARNESS WI	IRING - G	SENERATOR CONTROL Sets Without Meter Panel	41	301-3170 337-0049	1 1	Code 15R, 515R Strap, Ground
	338-0765	1	Code 3R	41			FOR STRAP
	338-0764	i	Code 15R, 515R		800-0046	1	Screw, Cap - Hex Head
	338-0766	1	Code 9XR, 6DR, 7R				(5/16-18 x 3/8")
			Sets With Meter Panel		850-0045	1	Washer, Lock - Spring (5/16")
	338-0735	1	Code 3R		856-0008 862-0015	2 1	Washer, Lock - EIT (5/16") Nut, Hex (5/16-18)
	338-0730 338-0759	1	Code 15R, 515R Code 9XR, 6DR, 7R	42	301-3158	1	Box, Control
			ARE FOR WIRING HARNESS	43	821-0010	2	Screw, Self-locking - Hex
	812-0061	2	Screw, Machine - Round Head				Washer Head (1/4-20 x 1/2")
			(#6-32 x 3/8")	44			RMER ASSEMBLY (See Separate
	812-0066	2	Screw, Machine - Round Head (#6-32 x 3/4")		Figure For the Contro		OTE: Assembly is Located Behind
	850-0020	2	Washer, Lock - Spring (#6)				
	853-0003 860-0006	4 2	Washer, Lock - ET (#6) Nut, Hex (#6-32)				
23			Select as Required)				
	332-0607	1	12 places				
	332-0795	1	16 places				
24	350-055 6	1	Resistor, Fixed Composition (47K Ohms, 1/2 Watt) - Code 15R, 515R				
25	323-0765	1	Socket, Relay - 11 Place - Code 15R, 515R	£-S	ee Separate F	Parts Catalo	og #900-0234 for Components.

^{* -} NOTE: For lamp replacement order 322-0178 remove and discard plain red lens, install lens with legend from burned out light —lights snap in and out of panel.



GENERATOR ASSEMBLY






GENERATOR ASSEMBLY

REF.	PART NO.	QTY. USED	. PART Description	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	800-0008	1	Screw, Cap - Hex Head (1/4-20 x 1-1/4")	27	812-0189	1	Screw, Machine - Round Head (3/8-16 x 3/4")
2	850-0040	1	Washer, Lock - Spring (1/4")	28	856-0010	1	Washer, Lock - EIT (3/8")
3	862-0001	1	Nut, Hex (1/4-20)	29	150-0717	1	Switch, Overspeed
4	234-0369	1	Cover, End Bell (Used on Housed Sets Only)	30			GENERATOR (Includes Parts
5	800-0003	2	Screw, Cap - Hex Head (1/4-20 x 1/2")		201-2666	1	50 Hertz 25 kw, Code 515
6	850-0040	2	Washer, Lock - Spring (1/4")		201-2669	1	±25 kw, Code 515 (Extended
7	150-1456		Contact Assembly - Overspeed		201-2009		Stack)
,	150-1450	1	Switch (Includes Parts		001 0000	1	60 Hertz
a	060 0001	2	Marked †)		201-2669		30 kw, Code 3
8	862-0001		†Nut, Hex (1/4-20)		201-2687	1	£30 kW, Code 3 (Environmental
9	853-0013	1	†Washer, Lock - ET (1/4")		201 2000	1	Protected)
10	150-0723	1	†Contact, Electrical		201-2666	1	30 kW, Code 6D, 9X, 15
11 12	870-0250	1	†Nut, Insulated		201-2668	1	30 kw, Code 7
13	150-1356	4	†Bracket, Mounting - Contact Nut, Hex - Grade 8 (3/8-16)		201-2669	Į	‡30 kW, Code 15 (Extended Stack)
14	862-0011	4			201 2684	1	£30 kW, Code 15 (Environmental
14 15	850-0050 STUD (Sele		Washer, Lock - Spring (3/8")		201-2684		Protected)
10	520-0718	u as nequ	3/8-16 UNC x 14-11/16" Lg		201-2687	1	£±30 kW, Code 15 (Extended Stack
	520-0710	4	3/8-16 UNC x 16-11/32" Lg		201-2001		and Environmental Protected)
16	503-0611	4	Hose, Rubber	31	800-0513	1	*Screw, Cap - Hex Head, Modified
17	800-0009	4	Screw, Cap - Hex Head	V.	000 00.0	•	with 3/8-16 Tapped Center
• • •	000 0000	•	(1/4-20 x 1-1/2")				Hole (3/4-10 x 1-1/2")
18	850-0040	4	Washer, Lock - Spring (1/4")	32	850-0079	1	*Washer, Lock - Spring (3/4")
19			Select as Required)	33	526-0238	1	*Washer, Flat - Steel Alloy
	220-2353	1	Standard			•	(3/16" ID x 2" OD x 3/16" Thk)
	220-1774	1	£Environmental Protected	34	510-0101	1	*Bearing, Ball
20	509-0125	1	Seal, Oil - "O" Ring	35	232-2102	1	*Spacer, Sleeve
21	211-0185	1	End Bell, Generator	36	*ROTOR AS	SEMBLY,	EXCITER (See Separate Group for
22	800-008	2	Screw, Cap - Hex Head		Component	ts)	
			(1/4-20 x 1-1/4")		201-1739	1	Standard
23	850-0040	2	Washer, Lock - Spring (1/4")		201-1845	1	£Environmental Protected
24	862-0001	2	Nut, Hex (1/4-20)	37	515-0145	1	*Key, Machine (1/4" x 1/4" x 7/8")
25	234-0368	1	Screen, Air - Generator	38	*BOLT, PLA	CE — HE	X HEAD, GRADE 8 (Select as
26	STATOR AS	SSEMBLY,	GÈNERATOR		Required)		
			50 HERTZ SETS		805-0033	8	5/8-11 x 1"
	220-1994	1	25 kw, Code 515		805-0035	8	5/8-11 x 1-1/2"
	220-1997	1	±25 kW. Code 515,	39	526-0259	8	*Washer, Flat - Hardened Steel
			(Extended Stack)				(11/16" ID x 1-3/8" OD x
			60 HERTZ SETS			o= 14E	7/64" Thk)
	220-1552	1	30 kw, Code 3	40		CE — HE	X HEAD, GRADE 8 (Select as
	220-1845	1	£30 kW, Code 3,		Required)		0/0.40 41/
	000 0001	_	(Environmental Protected)		805-0018	8	3/8-16 x 1"
	220-2621	1	30 kw, Code 6D	4.4	805-0019	8	3/8-16 x 1-1/4"
	220-2459	1	30 kw, Code 7	41	205-0089	1	*Fan, Generator *Disk, Drive - Generator
	220-1599	1	30 kw, Code 9X	42	232-2078	12	Screw, Cap — Socket Head
	220-1451	1	30 kw, Code 15 ‡30 kw, Code 15 (Extended Stack)	43	802-0072	12	(3/8-16 x 1")
	220-1454	1	£30 kw, Code 15 (Extended Stack)	44	850-0050	12	Washer, Lock - Spring (3/8")
	220-1783	1	(Environmental Protected)	44	231-0188	1	Adaptor, Generator
	220-1786	1 3	£‡30 kW, Code 15 (Extended Stack	40	201-0100	'	Maptor, demonator
	550-1100	, ,	and Environmental Protected)				

- † Parts included in Overspeed switch assembly
- * Parts included in Generator Rotor Assembly
- ‡ Extended Stack type assemblies that are used on sets having full power output on both single and three phase hookups. Both phases carry same KW and KVA ratings.
- $\pmb{\pounds}$ Environmental protected assemblies or parts which are coated with epoxy and are for use in high humidity areas.




CURRENT TRANSFORMER ASSEMBLY



								SC-1150
REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	
	CURRENT	TRANSFO	RMER ASSEMBLY (Select	. 7	CURRENT	TRANSFO	RMER (Select Size as Required	d)
	Component	ts as Requi	red		302-0117	3	Ratio 50/5, 3 VA	
1	GROUND T	ERMINAL	ASSEMBLY (Includes Following	- 1	302-0076	3	Ratio 75/5, 2 VA	
	Items)	•			302-0078	3	Ratio 100/5, 2 VA	
	815-0203	1	Screw, Machine - Round Head.		302-0079	3	Ratio 150/5, 1 VA	
			Brass (#10-32 x 7/8")		302-0106	3	Ratio 200/5, 1 VA	
	871-0010	·· 3.	Nut, Hex - Brass (#10-32)		302-0209	- 3	Ratio 230/5, 1 VA	
	856-0003	1.	Washer, Lock - EIT (#10)	•	302-0107	3	Ratio 300/5, 1 VA	
	854-0010	2	Washer, Lock - IT (#10)	-8	813-0100	6	Screw, Machine - Round Hea	ıd
	526-0049	2	Washer, Flat - Brass	1	2.		(#10-32 x 1/2")	
			(13/64" ID x 7/32" OD	9-	526-0008	6 -	Washer, Flat (13/64" ID x	
			x 1/32" Thk)		-	. 14	7/16" OD x 1/32" Thk)	
2	813-0110	6	Screw, Machine - Hound Head	10	856-0003	6	Washer, Lock - EIT (#10)	
			(#10-32 x 2")	11	870-0053	6	Nut, Hex (#10-32)	
3	854-0010	6	Washer, Lock - IT (#10)	12	CURRENT	TRANSFOR	RMER (Select Size as Required	1)
4	302-0235	. 3	Clamp, Upper		302-0952	3	Ratio 75/5, 2 VA	·
5	302-0236	3	Clamp, Lower		302-0864	3	Ratio 150/5, 2 VA	
6	302-0253	. 6	Shim		302-0865	. 3	Ratio 200/5, 2 VA	
					. 302-0866	. 3	Ratio 250/5, 2 VA	
					302-0608	3	Ratio 400/5, 2 VA	
					302-0547	3	Ratio 500/5, 2 VA	
			-		302-0471	3	Ratio 750/5, 2 VA	
				13	302-0729	. 1	Bracket, Mounting - Transfor	mer
				. 14	302-0764	1	Bracket, Mounting - Transfor	



EXCITER ROTOR




G-1030

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	ROTOR AS	SEMBLY, E	EXCITER (Includes Parts Marked *)
	201-1739	1	Standard
	201-1845	1	Enviromental Protected (Expoxyed)
1	813-0100	2	Screw, Machine - Round Head (#10-32 x 1/2")
2	870-0053	2	Nut, Hex (#10-32)
3	850-0030	2	Washer, Lock - Spring (#10)
4	526-0008	2	Washer, Flat (13/64" ID x 7/16" OD x 1/32" Thk)
5	813-0110	4	*Screw, Machine - Round Head (#10-32 x 2")
6	870-0053	4	*Nut, Hex (#10-32)
7	850-0030	4	*Washer, Lock - Spring (#10)
8	526-0009	4	*Washer, Flat (7/32" ID x 1/2" OD x 1/16" Thk)
9	508-0187	• 4	*Spacer, Stepped
10	332-0050	2	*Clamp, Loop
11	508-0093	2 2	*Grommet, Rubber
12	870-0053	6	*Nut, Hex (#10-32)
13	850-0030	6	*Washer, Lock - Spring (#10)
14	*DIODE, REG	CTIFIER - I	POSITIVE (CR1, CR2, CR3)
	358-0016	3	Standard
	358-0044	3	Enviromental Protected (Expoxyed)
15	*DIODE, REG	CTIFIER - I	NEGATIVE (CR4, CR5, CR6)
	358-0015	3	Standard
	358-0043	3	Enviromental Protected (Expoxyed)
16	363-0054	1	*Heat, Sink - Positive Diodes
17	363-0055	1	*Heat, Sink - Negative Diodes

^{* -} Parts included in Exciter Rotor Assembly







CHASSIS

REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. ŅO.	PART NO.	QTY. USED	PART DESCRIPTION
1	800-0520	2	Screw, Cap - Hex Head (3/4-10 x 1")	20	520-0663	2	Stud (5/16-18 x 5/16-18 x 3-1/4" Lg)
2	800-0095	2	Screw, Cap - Hex Head	21	416-0480	1	Frame, Holddown - Battery
			(1/2-13 x 2-1/4")	22	821-0029	6	Screw, Self-locking - Hex
3	850-0060	2	Washer, Lock - Spring (1/2")				Washer Head (3/8-16 x 3/4")
4	862-0016	2	Nut, Hex (1/2-13)	23	870-0281	6	Nut, Self-locking, Hex
5	800-0132	2	Screw, Cap - Hex Head				Washer Head (3/8-16)
			(5/8-11 x 1-1/2")	24	416-0666	1	Tray - Battery
6	850-0050	2	Washer, Lock - Spring (5/8")	25	800-0090	2	Screw, Cap - Hex Head
7	800-0091	2	Screw, Cap - Hex Head				(1/2-13 x 1")
			(1/2-13 x 1-1/4")	26	850-0060	2	Washer, Lock - Spring (1/2")
8	856-0013	2	Washer, Lock - External/Internal	27	862-0016	2	Nut, Hex (1/2-13)
			Tooth (1/2")	28	800-0520	1	Screw, Cap - Hex Head
9	850-0060	1	Washer, Lock - Spring (1/2")				(3/4-10 x 1")
10	862-0016	1	Nut, Hex (1/2-13)	29	402-0371	1	Mount, Vibration - Engine
11	337-0090	1	Strap, Electrical	30	403-1110	1	Support, Mounting - Engine
12	800-0028	1	Screw, Cap - Hex Head (5/16-18 x 1")	31	800-0071	4	Screw, Cap - Hex Head (7/16-14 x 1")
13	856-0008	1	Washer, Lock - External/Internal	32	850-0055	4	Washer, Lock - Spring (7/16")
			Tooth (5/16")	33	862-0004	4	Nut, Hex (7/16-14)
14	850-0045	1	Washer, Lock - Spring (5/16")	34	402-0030	2	Mount, Vibration - Generator
15	862-0015	1	Nut, Hex (5/16-18)	35	800-0091	4	Screw, Cap - Hex Head
16	332-1473	1	Terminal, Lug				(1/2-13 x 1-1/4")
17	865-0007	2	Nut, Wing (5/16-18)	36	850-0060	4	Washer, Lock - Spring (1/2")
18	850-0045	2	Washer, Lock - Spring (5/16")	37	232-2106	2	Bracket, Mounting - Generator
19	526-0115	2	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)	38	403-1111	1	Chassis






OPTIONAL EQUIPMENT SECTION

This section contains parts listing of factory installed options. NOTE: options may not be applicable to all models; for field installations, additional parts are usually required.



OPTIONAL ENGINE CONTROL WITH FIVE FAULT LIGHTS

H296





OPTIONAL ENGINE CONTROL WITH FIVE FAULT LIGHTS

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	322-0004	1	Lamp Incandescent (12 VDC)	26	860-0006	1	Nut, Hex (#6-32)
2	322-0149	1	Lampholder	27	853-0003	1	Washer, Lock - ET (#6)
3 4	308-0002 307-1157	1 3	Switch, Toggle (SPST) Spring, Holddown - Relay	28	356-0072	1	Capacitor, Fixed Electrolytic (4000 MFD, 30 VDC)
5	RELAY (12 V		Spring, Meladown Holay	29	812-0063	2	Screw, Machine - Round Head
Ŭ	307-1058	¹ 1	(Ignition)				(#6-32 x 1/2")
	307-1058	1	(Start Disconnect)	30	853-0003	2	Washer, Lock - ET (#6)
	307-1061	1	(Starter Protection)	31	356-0070	1	Clamp, Capacitor Mounting
7	193-0243	1	Gauge - Oil Pressure (12 VDC)	32	870-0053	1	Nut, Hex (#10-32)
8	193-0245	1	Gauge - Water Temperature	33	850~0030	1	Washer, Lock - Spring (#10)
			(12 VDC)	34	332-0051	1	Clamp, Loop
9	302-0061	1	Ammeter	35			ENGINE CONTROL
10	302-0749	1	£Tachometer - Electrical		338-1066	1	Includes Parts Marked †
11	193-0248	1	£Gauge - Oil Temperature			G HARDV	/ARE FOR WIRING HARNESS
10	CMITOU TO	00015	(12 VDC)		812-0063	6	Screw, Machine - Round Head
12	SWITCH, TO				040 0000	_	(#6-32 x 1/2")
	308-0138	1	Standard & Cycle Cranking Controls		812-0066	6	Screw, Machine - Round Head (#6-32 x 3/4")
	309-0327	1	Penn State Controls		853-0003	14	Washer, Lock - ET (#6)
13	*LIGHT, INDI	CATOR-1	4 VDC (Lens Color & Legend		860-0006	10	Nut, Hex (#6-32)
	Listed Below	/ }	-	36	332-1043	1	†Jumper, Terminal
	322-0107	1	Red - OVERCRANK	37	332-0795	1	†Block, Terminal - 20 Place
	322-0111	1	Red - OVERSPEED	38	332-0537	1	†Block, Terminal - 4 Place
	322-0108	1	Red - LO OIL PRESS	39	332-0699	1	†Block, Terminal - 6 Place
	322-0109	1	Red - HI ENG TEMP	40	323-0765	2	†Socket, Relay - 11 Place
	322-0110	2	Red - LO ENG TEMP	41	323-0764	2	†Socket, Relay - 8 Place
14	322-0136	1	*Light, Indicator - 14 VDC (Red	42	332-1271	1	†Connector, Electrical - PC BD
			Lens - No Legend)	43	332-1559	1	Strip, Marker - Terminal
15	518-0374	4	Fastener, Snap-In (Printed	44	332-1239	1	Strip, Marker - Terminal
			Circuit Boards)	45	332-1240	1	Strip, Marker - Terminal
16	PRINTED CI	RCUIT B	OARD ASSEMBLY (See Separate			ERMINAL	ASSEMBLY (Includes Parts
			34 for Components)		Marked #)	_,	(-11-11-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1
	300-0733	1	Standard Cranker (12 VDC)	46	871-0010	2	#Nut, Hex - Brass (#10-32)
	300-0714	i	Cycle Cranker (12 VDC)	47	850-0030	1	#Washer, Lock - Spring (#10)
17			OARD ASSEMBLY (See Separate	48	526-0205	2	#Washer, Flat - Brass (13/64" ID
• •	Parts Catalo		34 for Components)		020 0200		x 7/16" OD x 1/16" Thk)
	300-0681	1	Engine Control Monitor -	49	853-0008	1	#Washer, Lock - ET (#10)
			Standard	50	856-0003	1	#Washer, Lock - EIT (#10)
18	332-1276	4	Plug, Keying - PC Board	51	815-0203	1	#Screw, Machine - Round Head,
20	813-0098	2	Screw, Machine - Round Head		0.45 5000	~	Brass (#10-32 x 7/8")
21	850-0030	2	(#10-32 x 3/8") Washer, Lock - Spring (#10)	52	815-0026	5	Screw, Machine - Truss Head (#10-32 x 3/8")
22	526-0009	2	Washer, Flat (7/32" ID x 1/2" OD	53	870-0053	1	Nut, Hex (#10-32)
22	320 0000	_	x 1/16" Thk)	54	850-0030	1	Washer, Lock - Spring (#10)
23	856-0003	2	Washer, Lock - EIT (#10)	55	856-0003	1	Washer, Lock - EIT (#10)
24	307-1031	1	Relay, Solenoid - Start (12 VDC)	56	PANEL, CO		
25	812-0061	1	Screw, Machine - Round Head	30	301-3267	1	With Three Gauge Mtg. Holes
20	012-0001	1	(#6-32 x 3/8")		301-3286	1	With Four Gauge Mtg. Holes
			(#0-32 X 3/0)		301-3266	1	With Five Gauge Mtg. Holes
				E7	301-3166	1	Bracket, Mounting Engine
				57	001-0200	1	Control




^{*-}NOTE: For lamp replacement order 322-0136 remove and discard plain red lens, install lens with legend from burned out light — lights snap in and out of panel.

^{£ -} Optional items used with Engine Mounted Senders.

^{† -} Parts included in Wiring Harness

^{# -} Parts included in Ground Terminal Assembly




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION					
1	335-0110	. 1	Cable, Electrical (3 Wire)					
2	812-0090	2	Screw, Machine - Round Head (#6-32 x 2-1/4")					
3	860-0006	4	Nut, Hex (#6-32)					
4	856-0001	2	Washer, Lock - EIT (#6)					
5	301-1886	1	Cover, Thermostat					
6	309-0128	1	Thermostat - Adjustable					
7	800-0007	2	Screw, Cap - Hex Head (1/4-20 x 1")					
8	862-0001	2	Nut, Hex (1/4-20)					
9	850-0040	2	Washer, Lock - Spring (1/4)					
10	526-0052	2	Washer, Flat (17/64" ID x 9/16" OD x 1/16" Thk)					
11	862-0015	- 4	Nut, Hex (5/16-18) - Used As Spacers					
12	333-0151	1	Heater - 75 Watt, 120 VAC; 300 Watt, 240 VAC					



A177

OPTIONAL GENERATOR HEATER

179-2185



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	HEATER, G	ENERATO	R
	179-0369	1	120 Volt
	179-2185	1	240 Volt
1	CABLE ASS	EMBLY (Ir	ncludes Thermostat)
	335-0146	1	120 Volt
	335-0147	1	240 Volt
2	800-0004	1	Screw, Cap - Hex Head
			(1/4-20 x 5/8")
3	850-0038	1	Washer, Lock - Spring (1/4")
4	526-0158	1	Washer, Flat (17/64" ID
			1" OD x 1/8" Thk)
5	HEATER, EL	_ECTRICA	L
	333-0059	1	120 Volt, 125 Watt
	333-0192	1	240 Volt, 200 Watt



OPTIONAL CIRCUIT BREAKER

K481


K482

K483

K484

K491

K492








OPTIONAL CIRCUIT BREAKER

D		0.717	0.407				
REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
				11			
1	815-0350	6	Screw, Tapping - Hex Washer	11	320-0344	DREAKER (1	Select as Required) 175 AMP, 1 PH, 120/240 VAC
_	301-3192	1	Head (#10-32 x 3/8) Panel, Cover - Circuit Breaker		320-0344	1	150 AMP, 3 PH, 120/208 -
2 3			ION - SHRINKABLE (Select as		320-0340	'	120/240 VAC
3	Required)	INSULATI	ION - SHRINKABLE (Select as		320-0347	1	175 AMP, 3 PH, 120/208 -
	898-0863		3/4" ID		320-0347	'	120/240 VAC
	898-0865		1" ID		320-0348	1	200 AMP, 3 PH, 120/208 -
	898-0875		1-1/2" ID		020-0340	'	120/240 VAC
	898-0869		2" ID		320-0349	1	225 AMP, 3 PH, 120/208 VAC
4		INQLILATI	ION — FIBERGLASS (Select as		320-0359	ì	225 AMP, 1 PH, 120/240 VAC
7	Required)	MOOLAH	1014 — 1 IDENGEAGG (Select &		320-0379	1	90 AMP, 3 PH, 200/346 -
	898-0974		3/4" ID		020 0010	,	220/380 - 277/480 VAC
	898-0976		1" ID		320-0380	1	100 AMP, 3 PH, 200/346 -
5	800-0028	5	Screw. Cap ~ Hex Head		020 0000	•	220/380 - 277/480 VAC
9	000 0020	3	(5/16-18 x 1")		320-0384	1	60 AMP, 3 PH, 200/346 -
6	526-0022	10	Washer, Flat (21/64" ID x		000.	,	220/380 VAC
	020 0022		9/16" OD x 1/16" Thk)		320-0411	1	90 AMP, 3 PH, 120/240 VAC
7	850-0045	5	Washer, Lock - Spring (5/16")		320-0412	ì	100 AMP, 3 PH, 120/208 VAC
8	862-0015	5	Nut, Hex (5/16-18)		320-0413	i	50 AMP, 3 PH, 277/480 VAC
9	812-0094	4	Screw, Machine - Round Head		320-0414	i	70 AMP, 3 PH, 277/480 VAC
J	012 0004	-	(#8-32 x 3-5/8")		320-0415	i	40 AMP, 3 PH, 347/600 VAC
10	850-0025	4	Washer, Lock - Spring (#8)		320-0416	1	60 AMP, 3 PH, 347/600 VAC
	000 0020	•	Tradition and applying (ille)		320-0417	1	70 AMP, 3 PH, 347/600 VAC
					320-0418	1	90 AMP, 3 PH, 347/600 VAC
					320-0419	1	125 AMP, 3 PH, 200/346 -
							220/380 VAC
					320-0425	1	150 AMP, 3 PH, 200/346 VAC
					320-0726	1	150 AMP, 3 PH, 120/208 -
							120/240 VAC
					320-0823	1	50 AMP, 3 PH, 277/480 VAC
				12	800-0003	2	Screw, Cap - Hex Head
						•	(1/4-20 x 1/2")
				13	850-0040	2	Washer, Lock - Spring (1/4")
				14	301-3197	1	Bracket, Mounting - Circuit Breaker








REF. NO.	PART NO.	QTY. USED	PART Description	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	815-0026	2	Screw, Machine - Truss Head (#10-32 x 3/8")	13	815-0350	6	Screw, Tapping - Hex Washer Head (#10-32 x 3/8")
2	853-0008	2	Washer, Lock - External Tooth (#10)	14	812-0063	4	Screw, Machine - Round Head (#6-32 x 1/2")
3	301-3476	1	Cover - Transducer Box	15	853-0003	4.	Washer, Lock - External
4	508-0001	2	Grommet, Rubber (1-1/6" OD)			•	Tooth (#6)
5	860-0008	8	Nut, Hex (#8-32)	16	860-0006	4	Nut, Hex (#6-32)
6	853-0005	8	Washer, Lock - External	17	332-0609	1	Terminal, Strip
			Tooth (#8)	18	332-0610	1	Marker, Strip
7	526-0003	8	Washer, Flat (11/64" ID x 3/8" OD x 1/32" Thk)	19	302-1102	1	Wattmeter (Less Replaceable Dial)
8	402-0354	4	Mount, Vibration	20	DIAL WAT	IMETER (Select as Required)
9	TRANSDUCI	ER (Select	t as Required)		302-1103	1	Scale 0-35 kw
	302-1082		60 Hertz		302-1104	1	Scale 0-50 kw
	302-1083	1	50 Hertz		302-1105	Ì	Scale 0-70 kw
10	821-0014	8	Screw, Self-locking - Hex		302-1106	1	Scale 0-90 kw
			Washer Head (5/16-18 x 1/2")		302-1107	i	Scale 0-115 kw
11	402-0070	4	Mount, Vibration		302-1108	i	Scale 0-160 kw
12	301-3477	1	Box, Transducer		302-1109	i	Scale 0-180 kw
					302-1110	. i	Scale 0-200 kw




OPTIONAL OUTPUT BOX ASSEMBLY (HOUSED SETS)



REF. NO.			PART DESCRIPTION				
1	821-0005	٠ 4	Screw, Self-locking - Hex Washer Head (#10-32 x 1/2)				
2	301-3156	1	Panel, Access				
3	815-0350	2	Screw, Tapping - Hex Head, Slotted (#10-32 x 3/8)				
4	301-3195	1	Plate, Access - Button				
5	821-0014	2	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")				
6	821-0010	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1/2")				
7	301-3196	1	Bracket, Support - Current Transformer Assy				
8	508-0203	1	Bushing, Nylon				
9	301-3191	1	Box, Output				



F36






OPTIONAL SET HOUSING

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	813-0098	16	Screw, Machine - Round Head	14	406-0157	1	Handle, Latch (With Keys)
			(#10-32 x 3/8")	15	406-0089	1	Catch, Latch
2	850-0030	16	Washer, Lock ~ Spring (#10)	16	809-0059	3	Screw, Tapping - Pan Head
3	870-0053	16	Nut, Hex (#10-32)				(1/4 x 1/2")
4	406-0105	8	Clamp, Door (2 Required	17	870-0106	3	Nut, Sheet Spring (1/4")
			Each Door)	18	405-1777	1	Door, Access - Rear
5	405-1808	2	Door, Access, Louvered - Engine Section (Door Clamps	19	813-0098	. 6	Screw, Machine - Round Head (#10-32 x 3/8")
			Not Included)	20	850-0030	6	Washer, Lock - Spring (#10)
6	405-1832	2	Door, Access, Louvered - Generator Section, (Door	21	821-0014	8	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
			Clamps Not Included)	22	405-1780	1	Panel, Access - Rear
7	821-0014	8	Screw, Self-locking - Hex	23	405-1812	1	Panel, Housing - Rear
			Washer Head (5/16-18 x 1/2")	24	821-0010	8	Screw, Self-locking - Hex
8	405-1814	2	Support, Housing - Center				Washer Head (1/4-20 x 1/2")
9	821-0014	12	Screw, Self-locking - Hex	25	403-0895	2	Plate, Cover
			Washer Head (5/16-18 x 1/2")	26	821-0029	6	Screw, Self-locking - Hex
10	870-0113	12	Nut, Clinch (5/16-18)				Washer Head (3/8-16 x 3/4")
11	405-2151	1	Panel, Housing - Top	27	403-0894	1	Chassis - Rear
12	812-0149	2	Screw, Machine - Round Head (1/4-20 x 9/16")	28	814-0079	28	Screw, Machine - Flat Head (#8-32 x 1/2")
13	870-0232	2	Nut, Self-locking, Hex - With ET	29	850-0025	28	Washer, Lock - Spring (#8)
			Lockwasher (1/4-20)	30	860-0008	28	Nut, Hex (#8-32)
			• •	31	406-0249	4	Hasp Set - Optional



OPTIONAL DUAL PHASE SWITCH (UNHOUSED SETS)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	821-0014	2	Screw, Self-locking - Hex	6	862-0015	5	Nut, Hex (5/16-18)
			Washer Head (5/16-18 x 1/2")	7	812-0153	4	Screw, Machine - Round Head
2.	SLEEVING INSULATION - SHRINKABLE (Select as						(#1/4-20 x 1" Lg)
	Required)			8.	850-0040	4	Washer, Lock - Spring (1/4")
	898-0863		3/4" ID	-9	526-0052	. 4	Washer, Flat (17/64" ID x
	898-0865 1" ID						9/16" OD x 1/32" Thk)
	898-0875 1-1/2" ID		10	526-0054	4	Washer, Flat (21/64" ID x	
	898-0869		2" ID .	•			3/4" OD x 1/16" Thk)
	SLEEVING	INSULATE	ON — FIBERGLASS (Select as	11	308-0152	1	Switch, Rotary (Includes Knob)
	Required)		•	12	301-3292	1	Panel, Mounting - Switch
	898-0974		3/4" ID	13	812-0061	2	Screw, Machine - Round Head
	898-0976		1" ID				(#6-32 x 3/8")
3	800-0028	5	Screw, Cap - Hex Head	14	853-0003	2	Washer, Lock - External
			(5/16-18 x 1")				Tooth (#6)
4	526-0022	10	Washer, Flat (21/64" ID x	15	860-0006	2	Nut, Hex (#6-32)
			9/16" OD x 1/16" Thk)	16	307-1157	1	Spring, Holddown - Relay
5	850-0045	5	Washer, Lock - Spring (5/16")	17	307-1143	1	Relay
			· · · · · · · · · · · · · · · ·	18	323-0764	• 1	Socket, Relay

C12




OPTIONAL DUAL PHASE SWITCH (HOUSED SETS)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART Description
1	813-0098	6	Screw, Machine - Round Head	13	850-0040	4	Washer, Lock - Spring (1/4")
			(#10-32 x 3/8")	14	526-0052	4	Washer, Flat (17/64" ID x
2	850-0030	6	Washer, Lock - Spring (#10)				9/16" OD x 1/32" Thk)
3	821-0014 2 Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2		Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")	15	526-0054	4	Washer, Flat (21/64" ID x 3/4" OD x 1/16" Thk)
4	813-0097	4	Screw, Machine - Round Head	16	308-0152	1	Switch, Rotary (Includes Knob)
			(#10-32 x 5/16")	17	813-0097	4	Screw, Machine - Round Head
5	850-0030	4	Washer, Lock - Spring (#10)				(#10-32 x 5/16")
6	301-3284	1	Cover, Box	18	850-0030	4	Washer, Lock - Spring (#10)
7	7 SLEEVING, INSULATION - SHRINKABLE (SELECT				508-0009	1	Grommet, Rubber
	AS REQUIRED)		20	508-0115	2	Grommet, Rubber	
	898-0863	•	3/4" ID	21	301-3283	1	Box, Switch
	898-0865 1" ID		22	PANEL, AC	CESS - HC	DUSING REAR (Select Size	
	898-0875		1-1/2" ID		as Applicable)		
	898-0869		2" ID		405-1840	1	10-1/4" H x 22" W
	SLEEVING,	INSULATI	ON - FIBER GLASS		405-2160	1	14-1/2" H x 22" W
	(Select as R		•	23	812-0061	2	Screw, Machine - Round Head
	898-0974		3/4" ID				(#6-32 x 3/8")
	898-0976		1" ID	24	853-0003	2	Washer, Lock - External
8	800-0028	5	Screw, Cap - Hex Head				Tooth (#6)
			(5/16-18 x 1")	25	860-0006	2	Nut, Hex (#6-32)
9	526-0022	10	Washer, Flat (21/64" ID x	26	307-1157	1	Spring, Holddown - Relay
			9/16" OD x 1/16" Thk)	27	307-1143	1	Relay
10	850-0045	5	Washer, Lock - Spring (5/16")	28	323-0764	1	Socket, Relay
11	862-0015	5	Nut, Hex (5/16-18)				
12	812-0153	4	Screw, Machine - Round Head (#1/4-20 x 1" lg)				



944-0222 (JULY 1981)






OPTIONAL ENGINE COOLANT HEATER

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	ENGINE CO	OLANT H	EATER	16	CONNECTO	ORS	
	179-2058	1	115 Volt, 1 Phase		332-0149	8	Terminal, Lug (Used on White
	179-2090	1	480 Volt, 1 Phase				Leads)
	179-2094	1	240 Volt, 1 Phase		323-0957	2	Wire Nut (Used on Black Leads)
	179-2102	1	208 Volt, 1 Phase	17	309-0307	1	Switch, Pressure - Oil
	179-2112			18		•	by Applicable Voltage)
	179-2123	1	208 Volt, 3 Phase		307-1460	1	240 Volt, 30 Amp
	179-2130	1	480 Volt, 3 Phase		307-1164	1	480 Volt, 30 Amp
1	501-0227	1	Line, Fuel - Flexible	19	309-0304	1	Switch, Thermostatic
2	505-0007	2	Bushing, Reducer (1/4" NPT x 1/8" NPT)	20	505-0004	1	Nippie, Pipe - Close (1" NPT x 1-1/2" Lg)
3	503-0183	4	Clamp, Hose	21	800-0007	4	Screw, Cap - Hex Head
4	503-0843	1	Hose, Rubber (5/8" ID x				(1/4-20 x 1")
			61/64" OD x 40" Lg)	22	850-0040	4	Washer, Lock - Spring (1/4")
5	503-0833	1	Hose, Rubber (5/8" ID x	23	862-0001	4	Nut. Hex (1/4-20)
6	505-0135	4	61/64" OD x 24" Lg) Nipple, Pipe - Half (3/8" NPT x	24	505-0099	1	Nipple, Pipe - Close (1/4" NPT x 7/8" La)
	000 0100	,	1-1/2" Lg)	25	333-0142	1	Support with Tee - Pressure
7	504-0003	1	Cock, Drain (1/4" NPT)	20	000 07.12	-	Switch Mounting
8	505-0060	2	Tee, Pipe (3/8" NPT)	26	821-0016	4	Screw, Self-locking - Hex
9	505-0101	2	Nipple Pipe - Close		02. 00.0	•	Washer Head (5/16-18 x 3/4")
•	000 0101	_	(3/8" NPT x 1")	27	870-0257	4	Nut, Self-locking - Hex Washer
10	505-0131	1	Bushing, Reducer (3/4" NPT x		070 0201	•	Head (5/16-18)
10	300 0101	•	3/8" NPT)	28	130-1192	2	Bracket, Angle - Heater
11	505-0455	1	Bushing, Reducer	20	100 1102	_	Mounting
1 1	300 0433	'	(1" NPT x 3/8" NPT)	29	HEATER E	ECTRICA	AL - ENGINE COOLANT
12	331-0027	2	Clamp, Cable (3/8" OD Cable)	20	(Select As A		
13	#	٤.	Cord, Electrical - 2 #14, Type So,		333-0158	1	2000 Watts, 115 Volt, 1 Phase
10	17		600 Volt. 604		333-0167	1	2000 Watts, 208 Volt, 1 Phase
14	331-0027	4	Clamp, Cable (3/8" OD Cable) -		333-0148	1	2000 Watts, 200 Volt, 1 Phase
17	331 0027	7	Used with Contactor only		333-0141	1	2000 Watts, 240 Volt, 1 Phase
15	CARLE ELE	CTDICAL	(Type So, 600 Volt)		333-0176	1	2000 Watts, 240 Volt, 1 Phase
15	#	LUTHICAL	3 - #12 (Used on Single Phase		333-0170	i	2000 Watts, 380 Volt, 1 Hase
	17		Hookup)		333-0170	1	2000 Watts, 380 Volt, 3 Phase
	#		4 - #14 (Used on Three Phase		333-0147	1	2000 Watts, 480 Volt, 1 Phase
	π		Hookup)			-	
			(100καρ)	# Elect	rical Cable ar	nd Cord Sh	nown For Reference Purpose Only.



OPTIONAL COOLING SYSTEM (WITH HEAT EXCHANGER)




XCS1116



OPTIONAL COOLING SYSTEM WITH HEAT EXCHANGER

REF. NO.	PART NO.	QTY. USED	PART Description	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	179-1092	1	Cooling System with Heat	18	862-0001	2	Nut, Hex (1/4-20)
			Exchanger	19	110-0810	1	Bracket and Nipple Assembly
1 '	503-0429	2	Clamp, Hose				(3/4" NPT)
2	503-0961	1	Hose, Rubber - Preformed (1-1/2" ID & 1-3/4" ID)	20	821-0018	6	Screw, Self-locking - Hex Washer Head (1/4-20 x 5/8")
3	503-0365	2	Clamp, Hose	21	403-1461	1	Plate, Mounting - Standpipe
4	503-0962	1	Hose, Rubber (1-3/4" ID x 3-1/2" Lg)	22	813-0105	2	Screw, Machine - Round Head (#10-32 x 1" Lg)
5	503-0183	2	Clamp, Hose	23	870-0188	2	Nut, Self-locking, Hex (#10-32)
6	503-1000	1	Hose, Rubber (5/8" ID x 9" Lg)	24	130-1385	1	Band, Mounting -
7	505-0135	1	Nipple, Pipe - Half (3/8" NPT x				Heat Exchanger
			1-1/2" Lg)	25	130-1384	1	Band, Mounting -
8	505-0131	1	Bushing, Reducer - Hex				Heat Exchanger
			(3/4" NPT x 3/8" NPT)	26	130-0962	1	Heat Exchanger (Includes Cap)
9	505-0132	1	Elbow, Pipe - 90 DEG (3/4" NPT)	27		1	Cap, Pressure (Part of Heat
10	505-0102	1	Nipple, Pipe (3/4" NPT x				Exchanger)
			1-3/8" Lg)	28	130-1383	1	Brace, Support - Heat Exchanger
11	504-0019	1	Valve, Globe (3/4" NPT)	29	800-0051	2	Screw, Cap - Hex Head
12	505-0106	2	Nipple, Pipe (1/2" NPT x				(3/8-16 x 1-1/4")
			1-1/2" Lg)	30	130-1390	1	Bracket, Support -
13	307-0833	1	Valve, Control - Solenoid				Heat Exchanger
14	505-0021	1	Bushing, Reducer - Hex .	31	130-0954	1	Plate, Outlet - Engine Coolant
			(3/4" NPT x 1/2" NPT)	32	130-1386	1	Gasket ~ Outlet Plate
15	505-0029	2	Coupling, Pipe (3/4" NPT)	33	800-0052	1	Screw, Cap - Hex Head
16	800-0007	2	Screw, Cap - Hex Head				(3/8-16 x 1-1/2" Lg)
			(1/4-20 x 1" Lg)	34	850-0050	1	Washer, Lock - Spring (3/8")
17	850-0050	2	Washer, Lock - Spring (1/4")	35	517-0021	1	Plug, Button
			, -, -	36	130-0957	1	Guard, Belt









OPTIONAL COOLING SYSTEM (WITH CIRCULAR STANDPIPE)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	COOLING S	SYSTEM V	VITH STANDPIPE	20	309-0241	1	£Valve, Control - Temperature
	179-1090	1	†Without Coolant Temperature				Regulating
	179-1103	1	Regulator £With Coolant Temperature	21	800-0027	2	£Screw, Cap - Hex Head (5/16-18 x 7/8")
			Regulator	22	850-0045	2	£Washer, Lock - Spring (5/16")
1	503-0365	4	Clamp, Hose	23	862-0015	2	£Nut, Hex (5/16-18)
2	503-0727	1	Hose, Rubber - Preformed	24	110-0526	1	£Bracket and Nipple Assembly
_	505 5127	,	(1-3/4" ID x 1-1/2" ID)	25	505-0289	1	£Bushing, Reducer - Hex
3	503-0956	1	Hose, Rubber - with Spring				(1-1/2" NPT x 3/4" NPT)
·	000 0000	•	(1-3/4" ID)	26	505-0402	1	†Plug, Pipe - Square Head
4	505-0385	2	Nipple, Pipe - Half				(1-1/2" NPT)
7	300 0000	-	(1-1/2" NPT x 2" Lg)	27	505-0130	1	Plug, Pipe - Square Head
5	505-0462	2	Elbow, Pipe - 90 DEG		•••	•	(3/4" NPT)
	300 0402	_	(1-1/2" NPT)	28	505-0140	2	Plug, Pipe - Square Head
6	503-0189	2	£Clamp, Hose		000 01.0	_	(1" NPT)
7	503-0437	1	£Hose, Rubber (3/4" ID x	29	504-0028	1	Cock, Drain (3/8" NPT)
,	303-0431	'	7-1/2" Lg)	30	505-0028	1	Coupling, Pipe (3/8" NPT)
8	505-0185	2	£Nipple, Pipe - Half (1/2" NPT x	31	505-0101	i	Nipple, Pipe - Close
Ü	303-0103	-	1-1/2" Lg)	0.	000 0101	•	(3/8" NPT x 1")
9	307-0833	4	Valve, Control - Solenoid	32	504-0062	1	Valve. Relief - Vacuum
10	505-0100	i	Nipple, Pipe - Close	33	800-0048	4	Screw, Cap - Hex Head
10	303-0100	ı	(1/2" NPT x 1-1/8" Lg)	00	000 0040	7	(3/8-16 x 3/4")
11	504-0019	1	†Valve, Globe (1/2" NPT)	34	850-0050	4	Washer, Lock - Spring (3/8")
12	505-0040	2	£Elbow, Pipe - 90 DEG (1/2" NPT)	35	862-0003	4	Nut, Hex (3/8-16)
13	505-0100	1	Nipple, Pipe - Close (1/2" NPT x	36	130-0635	1	Tank, Stand Pipe
-			1-1/8" Lg)	37	821-0018	6	Screw, Self-locking - Hex
14	505-0021	1	Bushing, Reducer - Hex				Washer Head (1/4-20 x 5/8")
			(3/4" NPT x 1/2" NPT)	38	403-1461	1	Plate, Mounting - Standpipe
15	504-0028	1	£Cock, Drain (3/8" NPT)	39	800-0052	1	Screw, Cap - Hex Head
16	505-0019	1	£Bushing, Reducer - Hex				(3/8-16 x 1-1/2")
	-		(1/2" NPT x 3/8" NPT)	40	850-0050	1	Washer, Lock - Spring (3/8")
17	505-0108	1	£Tee, Pipe (1/2" NPT)	41	517-0021	1	Plug, Button
18	505-0002	i	£Nipple, Pipe (1/2" NPT x 3" Lg)	42	130-0957	1 .	Guard, Belt
19	505-0021	2	£Bushing, Reducer - Hex			on Non-re	gulated System.
			(3/4" NPT x 1/2" NPT)	£ - Par	ts used only	on Regula	ted System.




^{£ -} Parts used only on Regulated System.

OPTIONAL COOLING SYSTEM (WITH SQUARE STANDPIPE)

E13

E45





OPTIONAL COOLING SYSTEM (CITY WATER)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART Description
	COOLINGS	SYSTEM (City Water)	19	821-0014	6	Screw, Self-locking - Hex
	179-1023	1	Without Coolant Temperature				Washer Head (5/16-18 x 1/2")
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	•	Regulator	20	130-0499	1	Plate, Mounting
	179-1024	1	With Coolant Temperature	21	110-0576	1	Adapter, Hose
		•	Regulator	22	505-0040	1	£Elbow, Pipe - 90 DEG (1/2" NPT)
1	503-0189	4	Clamp, Hose	23	505~0100	1	£Nipple, Pipe - Close
2	503-0973	1	Hose, Rubber (3/4" 1D x				(1/2" NPT x 1-1/8" Lg)
_			1-1/8" OD x 20" Lg)	24	505-0022	1	Bushing, Reducer - Hex
3	503-0436	1	Hose, Rubber (3/4" ID x				(1" NPT x 1/2" NPT)
-			1-1/8" OD x 14-1/2" Lg)	25	505-0041	1	†Elbow, Pipe - 90 DEG (1" NPT)
4	503-0365	2	Clamp, Hose	26	505-0129	1	£Bushing, Reducer - Hex
5	503-0826	1	Hose, Rubber (1-3/4" ID x				(1" NPT x 3/4" NPT)
-			2-1/8" OD x 3" Lg)	27	505-0304	1	£Tee, Pipe (1" NPT)
6	505-0185	4	Nippie, Pipe-Half	28	505-0004	1	†Nipple, Pipe - Close
			(1/2" NPT x 1-1/2")				(1" NPT x 1-1/8")
7	504-0063	1	Cock, Drain (1/4" NPT)	29	505-0086	1	£Nipple, Pipe (1" NPT x 2-1/2")
g	505-0018	1	Bushing, Reducer - Hex	30	505-0003	1	Elbow, Pipe - Street, 90 DEG
_			(1/2" NPT x 1/4" NPT)				(1" NPT)
9	505-0108	2	Tee, Pipe (1/2" NPT)	31	505-0304	1	Tee, Pipe (1" NPT)
10	505-0100	2	Nipple, Pipe - Close	32	505-0004	1	Nipple, Pipe - Close
			(1/2" NPT x 1-1/8")				(1" NPT x 1-1/8")
11	505-0021	2	£Bushing, Reducer - Hex	33	800-0051	2	Screw, Cap - Hex Head
			(3/4" NPT x 1/2" NPT)				(3/8-16 x 1-1/4")
12	309-0241	1	£Valve, Control - Temperature	34	130-0954	1	Plate, Outlet - Engine Coolant
			Regulating	35	130-1386	1	Gasket, Thermostat
13	307-0833	1	Valve, Control - Solenoid	36	517-0021	1	Plug, Button
14	504-0019	1	†Valve, Globe	37	800-0052	1	Screw, Cap - Hex Head
15	800-0007	2	Screw, Cap - Hex Head				(3/8-16 x 1-1/2")
			(1/4-20 x 1")	38	850-0050	1	Washer, Lock - Spring (3/8")
16	850-0040	2	Washer, Lock - Spring (1/4")	39	130-0957	1	Guard, Belt
17	862-0001	2	Nut, Hex (1/4-20)	+ - Par	ts used on Ni	nn-Regula	ited System
18	110-0526	1	Bracket and Nipple Assembly	† - Parts used on Non-Regulated System.			


 $^{{\}bf \pounds}$ - Parts used on Regulated System.



OPTIONAL COOLING SYSTEM (CITY WATER WITH WATER COOLED MANIFOLD)

E5

E45



XCS1120




OPTIONAL COOLING SYSTEM (WITH SQUARE STANDPIPE)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	COOLING S	YSTEM V	VITH STANDPIPE	20	309-0241	1	£Valve, Control - Temperature
	179-1020	1	†Without Coolant Temperature				Regulating
			Regulator	21	800-0027	2	£Screw, Cap - Hex Head
	179-1021	1	£With Coolant Temperature				(5/16-18 x 7/8")
			Regulator	22	850-0045	2	£Washer, Lock - Spring (5/16")
1	503-0365	4	Clamp, Hose	23	862-0015	2	£Nut, Hex (5/16-18)
2	503-0724	1	Hose, Rubber - Preformed	24	110-0526	1	£Bracket and Nipple Assembly
			(1-3/4" ID x 1-1/2" ID)	25	505-0129	1	£Bushing, Reducer - Hex
3	503-0635	1	Hose, Rubber - with Spring				(1" NPT x 3/4" NPT)
			(1-3/4" 1D)	26	505-0140	1	†Plug, Pipe - Square Head
4	505-0031	1	Coupling, Pipe (1-1/4" NPT)				(1" NPT)
5	505-0177	1	Nipple, Pipe - Close	27	505-0056	1	Plug, Pipe - Square Head
			(1-1/4" NPT)				(1/2" NPT)
6	503-0189	2	£Clamp, Hose	28	505-0130	2	Plug, Pipe - Square Head
7	503-0437	1	£Hose, Rubber (3/4" ID x				(3/4" NPT)
-			7-1/2" Lg)	29	504-0028	1	Cock, Drain (3/8" NPT)
8	505-0185	2	£Nipple, Pipe - Half (1/2" NPT x	30	505-0028	1	Coupling, Pipe (3/8" NPT)
-		_	1-1/2" Lg)	31	505-0101	1	Nipple, Pipe - Close
9	307-0833	1	Valve, Control - Solenoid				(3/8" NPT x 1")
10	505-0100	1	Nipple, Pipe - Close	32	504-0062	1	Valve, Relief - Vacuum
	000 0.00	•	(1/2" NPT x 1-1/8" Lg)	33	800-0048	4	Screw, Cap - Hex Head
11	504-0019	1	†Valve, Globe (1/2" NPT)				(3/8-16 x 3/4")
12	505-0040	2	£Elbow, Pipe - 90 DEG (1/2" NPT)	34	850-0050	4	Washer, Lock - Spring (3/8")
13	505-0100	1	Nipple, Pipe - Close (1/2" NPT x	36	130-0659	1	Tank, Stand Pipe
		•	1-1/8" La)	37	821-0018	6	Screw, Self-locking - Hex
14	505-0949	1	Plug, Pipe - Socket Head				Washer Head (1/4-20 x 5/8")
	000 00.0		(1-1/4" NPT)	38	130-0860	1	Plate, Mounting - Stand Pipe
15	504-0028	1	£Cock, Drain (3/8" NPT)	39	800-0052	1	Screw, Cap - Hex Head
16	505-0019	1	£Bushing, Reducer - Hex				(3/8-16 x 1-1/2")
	050 0010		(1/2" NPT x 3/8" NPT)	40	850-0050	1	Washer, Lock - Spring (3/8")
17	505-0108	1	£Tee, Pipe (1/2" NPT)	41	517-0021	1	Plug, Button
18	505-0002	ì	£Nipple, Pipe (1/2" NPT x 3" Lg)	42	130-0957	1	Guard, Belt
19	505-0021	2	£Bushing, Reducer - Hex			on Non-Re	egulated System.
			(3/4" NPT x 1/2" NPT)	f - Par	ts used only i	on Regula	ted System



^{£ -} Parts used only on Regulated System.






OPTIONAL COOLING SYSTEM (CITY WATER WITH WATER **COOLED MANIFOLD)**

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	COOLING S Manifold)		City Water with Water Cooled	24 25	850-0040 862-0001	2 2	Washer, Lock - Spring (1/4″) Nut, Hex (1/4-20)
	179-1019	1	Without Coolant Temperature	25 26	110-0526	1	Bracket and Nipple Assembly
	179-1019	1	•	27	821-0018	6	Screw, Self-locking, - Hex
	179-1022	1	Regulator With Coolant Temperature	21	021-0010	0	Washer Head (1/4-20 x 5/8")
			Regulator	28	130-0499	1	Plate, Mounting
1	503-0685	1	Clamp, Hose	29	505-0802	1	Bushing, Reducer - Hex
2	501-0201	1	Line, Fuel - Flexible				(1" NPT x 1/4" NPT)
3	502-0002	1	Elbow, Pipe - Street, 90 DEG (Inverted Male)	30	505-0129	1	£Bushing, Reducer - Hex (1" NPT x 3/4" NPT)
4	503-0183	. 4	Clamp, Hose	31	505-0304	1	£Tee, Pipe (1" NPT)
5	503-0189	2	Clamp, Hose	32	505-0086	1	£Nipple. Pipe (1" NPT x 2-1/2")
6	503-0185	1	Hose, Rubber (1/2" ID x	33	505-0003	i	Elbow, Pipe - Street, 90 DEG
Ü		•	27/32" OD x 16" Lg)				(1" NPT)
7	503-1031	1	Hose, Rubber (1/2" ID x	34	505-0304	1	Tee, Pipe (1" NPT)
			27/32" OD x 11" Lg)	35	505-0004	1	Nipple, Pipe - Close (1" NPT x
8	503-1012	1	Hose, Rubber (3/4" ID x		200 2054		1-1/2")
_		_	61/64" OD x 27" Lg)	36	800-0051	2	Screw, Cap - Hex Head
9	503-0365	2	Clamp, Hose		100 0051		(3/8-16 x 1-1/4")
10	503-0826	1	Hose, Rubber (1-3/4" ID x	37	130-0954	1	Plate, Outlet - Engine Coolant
		_	2-1/8" OD x 3" Lg)	38	130-1386	1	Gasket - Thermostat
11	502-0304	3	Elbow, Pipe - 90 DEG (1/4" NPT)	39	505-0201	1	Elbow, Pipe - Street (2" NPT)
12	505-0184	2	Tee, Pipe (1/4" NPT)	40	505-0801	1	Bushing, Reducer - Flush
13	505-0099	2	Nipple, Pipe - Close			_	(2-1/2" NPT x 2" NPT)
			(1/4" NPT x 7/8")	41	154-1739	1	Flange, Pipe - Exhaust Outlet
14	505-0185	2	Nipple, Pipe - Half	42	154-1738	1	Manifold, Exhaust - Liquid
			(1/2" NPT x 1-1/2")				Cooled (Includes Items
15	505-0302	1	Nipple, Pipe - Half				Marked *)
			(1/4" NPT x 1-1/2")	43	870-0195	4	*Nut, Self-locking, Hex (5/16-24)
16	504-0063	1	Cock, Drain (1/4" NPT)	44	850-0165	4	*Washer, Lock - Spring, SST
17	505-0018	2	Bushing, Reducer - Hex				(5/16")
18	505-0021	2	(1/2" NPT x 1/4" NPT) £Bushing, Reducer - Hex	45	520-0108	4	*Stud (5/16-24 x 5/16-18 x 1-9/16" Lg)
16	500-0021	2	(3/4" NPT x 1/2" NPT)	46	154-2336	1	*Gasket - Exhaust Header
40	110 0570	4	Adapter, Hose	47	517-0021	1	Plug, Button
19	110-0576	1	£Valve, Control - Temperature	48	800-0052	1	Screw, Cap - Hex Head
20	309-0241	1	Regulating	40	600-0032	'	(3/8-16 x 1-1/2" Lg)
21	307-0833	1	Valve, Control - Solenoid	49	850-0050	1	Washer, Lock - Spring (3/8")
22	504-0019	1	†Valve, Globe (Non-Regulating	50	130-0957	1	Guard, Belt
			Application)	† - Par	ts used only o	on Non-Re	egulated System.
23	800-0037	2	Screw, Cap - Hex Head (1/4-20 x 1")		ts used only o		-
			(1/120 8 1)	* De-	da Inalijalad u	المطابات طفان	at Manifold




^{* -} Parts Included with Exhaust Manifold.



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
. 1	501-0167	1	Line, Fuel - Flexible
2	501-0005	1	Line, Fuel - Flexible
3	502-0003	2	Connector, Line - Inverted Male
- 4	502-0638	1	Adapter - Pipe to Line
5	800-0005	2	Screw, Cap - Hex Head (1/4-20 x 3/4")
6	850-0050	2	Washer, Lock - Spring (1/4")
7	526-0015	2	Washer, Flat (9/32" ID x 9/16" OD x 1/16" Thk)
8	149-1613	1	Filter - Fuel (Includes Element)
9	149-1691	1 .	Element - Fuel Filter
10	800-0090	.4	Screw, Cap - Hex Head (1/2-13 x 1")
11	850-0060	4	Washer, Lock - Spring (1/2")
12	526-0028	4	Washer, Flat (9/16" ID x 15/16" OD x 1/16" Thk)
13	149-1614	1	Bracket, Mounting - Fuel Filter



OPTIONAL EXHAUST MANIFOLD (LIQUID COOLED)



XEXS1053

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	503-0685	1	Clamp, Hose	10	502-0210	2	Bushing, Reducer - Hex
2	501-0201	1	Line, Fuel - Flexible				(1/2" NPT x 1/4" NPT)
3	502-0002	1	Elbow, Pipe - Street, 90 DEG (Inverted Male)	11	505-0201	1	Elbow, Pipe - Street, 90 DEG (2" NPT)
4	503-0183	4	Clamp, Hose	12	154-2076	. 1	Flange, Pipe - Exhaust Outlet
5	503-0119	1	Hose, Rubber (1/2" ID x 18-1/2" Lg)	13	154-1754	1	Manifold, Exhaust - Liquid Cooled (Includes Parts
6	503-0285	1	Hose, Rubber (1/2" ID x 14" Lg)				Marked *)
7	505-0302	1	Nipple, Pipe - Half (1/4" NPT x	14	870-0195	4	*Nut, Self-locking, Hex (5/16-24)
			1-1/2")	15	850-0165	4	*Washer, Lock - Spring, SST
8	505-0011	1	Elbow, Pipe - Street, 90 DEG				(5/16")
			(1/4" NPT)	16	520-0108	4	^Stud (5/16-24 x 5/16-18 x
9	502-0304	2	Elbow, Pipe - 90 DEG, Brass				1-9/16" Lg)
			(1/4" NPT)	17	154-2336	1	*Gasket - Exhaust Header
				* - Pari	ts included	with Exhau:	st Manifold.



179-1520

OPTIONAL EXHAUST MUFFLER (HOUSED SETS)


A76

179-1554

179-1576

179-1606

179-1616



EXS-1049




OPTIONAL EXHAUST MUFFLER (HOUSED SETS)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	EXHAUST MUFFLER		Industrial Type	11	870-0257	3	Nut, Self-locking, Hex Washer Head (5/16-18)
	179-1520	1	Standard Muffler	12	MUFFLER.	EXHAUST	(Select as Applicable)
	179-1616	1	Standard Muffler		155-0988	1	Industrial (10" OD x 43" Lg)
	179-1554	1	Stainless Steel Muffler		155-1512	1	Industrial, SST
	179-1606	1	Stainless Steel Muffler				(10" OD x 43" Lg)
			Residential/Critical Types		155-1617	1	Critical (12" OD x 44" Lg)
	179-1576	1	Critical Muffler	13	800-0037	6	Screw, Cap - Hex Head
1	813-0105	1	Screw, Machine - Round Head				(5/16-18 x 3")
			(#10-32 x 1")	14	870-0048	6	Nut, Self-locking, Hex (5/16-18)
2	870-0188	1	Nut, Self-locking, Hex (#10-32)	15	BAND, MO	UNTING -	MUFFLER
3	155-1421	1	Shield, Rain (2-1/2" ID)		140-0649	3	10" ID
4	895-0158	1	Asbestos, Strip (2" x 10" x		140-1588	3	10" ID, SST
			1/16" Thk)		140-0752	3	12" ID
5	505-0454	1	Union, Pipe (2" NPT)	16	155-1430	6	Spacer, Sleeve (1/2" ID x
6	505-0172	1	Nipple, Pipe - Close				1-1/2" OD x 2" Thk)
			(2" NPT x 2" Lg)	17	HEAT SHIE	LD	
7	TUBE, EXHA	UST			155-0978	1	10" W x 36" Lg
	155-1591	1	2" NPT x 10-3/4" Lg		155-1644	1	10" W x 36" Lg, SST
	155-1649	1	2" NPT x 11-7/8" Lg		155-1648	1	10" W x 40" Lg, SST
8	505-0175	1	Elbow, Pipe - 90 DEG (2" NPT)	18	800-0026	6	Screw, Cap - Hex Head
9	800-0037	3	Screw, Cap - Hex Head				(5/16-18 x 3/4")
			(5/16-18 x 3")	19	870-0048	6	Nut, Self-locking, Hex (5/16-18)
10	526-0113	6	Washer, Flat (11/32" ID x 1" OD x 3/32" Thk)	20	155-0789	3	Support, Mounting - Muffler



OPTIONAL FUEL TANK — MOUNTED (HOUSED SETS)

179-0463





OPTIONAL FUEL TANK-MOUNTED (HOUSED SETS)


REF.	PART NO.	QTY. USED	PART DESCRIPTION
	179-0442	1	Mounted Fuel Tank
	179-0463	1	Mounted Fuel Tank with Three Way Valves
1	503-0685	1	Clamp, Hose (1/2" OD Hose)
2	501-0205	1	Line, Fuel - Flexible (72")
3	501-0027	1	Line, Fuel - Flexible (48")
4	504-0013	1	Valve, Shutoff - with Screen (1/8" NPT)
5	504-0007	1	*Valve, Shutoff (1/8" NPT)
6	502-0017	1	£Connector, Inverted Female
7	502-0046	1	£Nipple, Pipe - Close, Brass (1/8" NPT x 3/4" Lg)
8	504-0004	2	£Valve, Shutoff - 3 Way
9	505-0057	1	Pług, Pipe - Square Head (1/8" NPT)
10	159-0512	1	Cap and Indicator, Fuel (Includes Gasket)
11	159-0751	1	Gasket, Fuel Cap
12	812-0158	2	Screw, Machine - Round Head (1/4-20 x 2")
13	850-0040	2	Washer, Lock - Spring (1/4")
14	159-1025	1	Tank, Fuel - 20 Gal
15	821-0010	8	Screw, Self-locking - Hex Washer Head (1/4-20 x 1/2")
16	159-0489	1	Strap Assembly - Tank Mounting

^{* -} Parts used only on 179-0442 Tank.



^{£ -} Parts used only on 179-0463 Tank.

OPTIONAL FUEL TANK RESERVOIR (HOUSED SETS)






OPTIONAL FUEL TANK RESERVIOR (HOUSED SETS)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	FUEL TANK RESERVIOR		17	813-0098	1	Screw, Machine - Round Head	
	179-0513	1	For Housed Sets				(#10-32 x 3/8")
1	502-0051	1	Coupling, Pipe - Brass	18	850-0030	1	Washer, Lock - Spring (#10)
			(1/4" NPT)	19	415-0326	1	Cover, Access - Relay
2	501-0008	1	Line, Fuel - Flexible	20	812-0061	2	Screw, Machine - Round Head
3	501-0015	1	Line, Fuel - Flexible				(#6-32 x 3/8")
4	502-0041	2	Elbow, Pipe - Street, 90 DEG,	21	870-1183	2	Nut, Self-locking, Hex - with
			Brass (1/4" NPT) - Inverted Male				External Tooth Lock Washer (#6-32)
5	503-0685	1	Clamp, Hose	22	307-1157	1	Spring, Hold Down - Relay
6	501-0226	1	Line, Fuel - Flexible	23	307-1058	1	Relay - 12 VDC
7	502-0020	1	Elbow, Pipe - Street, 90 DEG,	24	323-0897	1	Socket, Relay (Included Leads)
			Brass (1/8" NPT)	25	821-0014	6	Screw, Self-locking - Hex
8	502-0029	1	Bushing, Reducer - Hex				Washer Head (5/16-18 x 1/2")
			(1/4" NPT x 1/8" NPT)	26	402-0070	4	Mount, Vibration
9	159-0007	1	Cap, Fuel Tank	27	415-0324	1	Bracket, Mounting - Fuel Tank
10	332-0556	4	Connector, Splice	28	870-0048	2	Nut, Self-locking, Hex Washer
.11	415-0335	1	Switch, Float - Liquid Level				Head (5/16-18)
12	505-0054	1	Plug, Pipe - Square Head (1/4" NPT)	29	821-0016	2	Screw, Self-locking - Hex Washer Head (5/16-18 x 3/4")
13	505-0110	1	Plug, Pipe - Square Head (3/8" NPT)	30	821-0018	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 5/8")
14	821-0013	2	Screw, Self-locking - Hex	31	149-1830	1	Pump, Fuel - Electric, 12 VDC
			Washer Head (1/4-20 x 1")	32	821-0014	2	Screw, Self-locking - Hex
15	415-0323	1	Strap, Retaining - Tank				Washer Head (5/16-18 x 1/2")
16	415-0325	1	Tank, Fuel - Dav	33	130-1005	1	Bracket, Mounting - Fuel Pump



OPTIONAL FUEL TANK RESERVOIR (UNHOUSED SETS)





OPTIONAL FUEL TANK RESERVIOR (UNHOUSED SETS)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	FUEL TANK RESERVIOR		16	415-0325	1	Tank, Fuel - Day	
	179-1599	1	For Unhoused Sets	17	813-0098	1	Screw, Machine - Round Head
1	502-0051	1	Coupling, Pipe - Brass				(#10-32 x 3/8")
			(1/4" NPT)	18	850-0030	1	Washer, Lock - Spring (#10)
2	501-0008	1	Line, Fuel - Flexible	19	415-0326	1	Cover, Access - Relay
3	501-0007	1	Line, Fuel - Flexible	20	812-0061	2	Screw, Machine - Round Head
4	502-0041	2	Elbow, Pipe - Street, 90 DEG,				(#6-32 x 3/8")
			Brass (1/4" NPT) - Inverted Male	21	870-1183	2	Nut, Self-locking, Hex - with External Tooth Lock Washer
5	503-0685	1	Clamp, Hose				(#6-32)
6	501-0226	1	Line, Fuel - Flexible	22	307-1157	1	Spring, Hold Down - Relay
7	502-0020	2	Elbow, Pipe - Street, 90 DEG,	23	307-1058	1	Relay - 12 VDC
			Brass (1/8" NPT)	24	323-0897	1	Socket, Relay (Includes Leads)
8	502-0029	1	Bushing, Reducer - Hex (1/4" NPT x 1/8" NPT)	25	821-0014	8	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
9	159-0007	1	Cap, Fuel Tank	26	402-0070	4	Mound, Vibration
10	332-0556	4	Connector, Splice	27	415-0324	1	Bracket, Mounting - Fuel Tank
11	415-0335	1	Switch, Float - Liquid Level	28	821-0014	2	Screw, Self-locking - Hex
12	505-0054	1	Plug, Pipe - Square Head				Washer Head (5/16-18 x 1/2")
			(1/4" NPT)	29	403-1118	1	Plate, Support - Fuel Tank
13	505-0110	1	Plug, Pipe - Square Head (3/8" NPT)	30	821-0018	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 5/8")
14	821-0013	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1")	31	870-0212	2	Nut, Self-locking - Hex Washer Head (1/4-20)
15	415-0323	1	Strap, Retaining - Tank	32	149-1830	1	Pump, Fuel - Electric, 12 VDC






179-2150 179-2155

OPTIONAL FUEL TANK RESERVOIR (OVERHEAD/UNDERGROUND APPLICATIONS)

C129

C130






OPTIONAL FUEL TANK RESERVIOR (OVERHEAD/UNDERGROUND APPLICATIONS)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	
	FUEL TANK RESERVIOR				821-0013	2	Screw, Self-locking - Hex	
	179-2150	1	Overhead Tank Application				Washer Head (1/4-20 x 1")	
	179-2155	1	Underground Tank Application	18	415-0451	1	Strap, Retaining - Fuel Tank	
1	501-0226	1	Line, Fuel - Flexible	19	415-0468	1	Tank, Fuel - Day (Includes	
2	501-0321	1	Line, Fuel - Flexible				Access Cover Plate)	
3	502-0029	1	Bushing, Reducer - Hex	20	415-0516	1	Plate, Cover - Access	
			(1/4" NPT x 1/8" NPT)	21	821-0004	2	Screw, Self-locking - Hex	
4	502-0020	1	Elbow, Pipe - Street, 90 DEG				Washer Head (#10-32 x 5/16")	
			(1/8" NPT)	22	415-0464	1	Cover, Access - Relay	
5	502-0029	1	Bushing, Reducer - Hex	23	307-1058	1	Relay - 12 VDC	
			(1/4" NPT x 1/8" NPT)	24	812-0079	2	Screw, Machine - Round Head	
6	332-0556	4	Connector, Splice				(#8-32 x 1/2")	
7	415-0473	1	Switch, Float - Liquid Level	25	323-0804	1	Socket, Relay	
8	159-0007	1	Cap - Fuel Tank	26	821-0014	8	Screw, Self-locking - Hex	
9	502-0155	2	Plug, Pipe - Square Head, Brass				Washer Head (5/16-18 x 1/2")	
			(3/8" NPT)	27	402-0078	4	Mount, Vibration	
10	505-0057	1	†Plug, Pipe - Square Head (1/8" NPT)	28	821-0007	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1/4")	
11	307-1819	1	£Solenoid - 12 VDC	29	415-0463	1	Box, Control - Relay	
12	505-0098	1	£Nipple, Pipe - Close	30	415-0471	1	Bracket, Mounting - Fuel Tank	
	•		(1/8" NPT x 3/4")	31	821-0014	6	Screw, Self-locking - Hex	
13	800-0002	6	Screw, Cap - Hex Head				Washer Head (5/16-18 x 1/2")	
	• • • • • • • • • • • • • • • • • • • •		(1/4-20 x 3/8")	32	870-0045	3	Nut, Hex (5/16-18)	
14	526-0063	6	Washer, Flat - Copper (17/64" ID	33	415-0449	1	Bracket, Support - Fuel Tank	
			x 7/16" OD x 1/32" Thk)	+ - Dar	te uead anly i	n Underar	ound Tank Application.	
15	415-0467	1	Gasket - Access Plate		-	_	' '	
16	309-0401	1	£Valve, Float	${\mathfrak L}$ - Parts used only in Overhead Tank Application.				






REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION			REF.	PART NO.	QTY USED	PART DESCRIPTION
1	503-1077	1	Hose, Rubber - High Pressure	٠.		13	812-0066	2	Screw, Machine - Round Head
			(1/4" ID x 1/2" OD x 96")						(#6-32 x 3/4")
. 2	502-0444	1	Adapter, Pipe to Hose - Male			14	853-0003	2	Washer, Łock - ET. (#6)
			(1/8" NPT x 1/4" ID Hose)			15	. 332-0795	1	Block, Terminal - 20 Place
3	502-0445	1	Adapter, Pipe to Hose - Female			. 16	332-1241	1	Strip, Marker - Terminal
			(7/16-20 UNF x 1/4" ID Hose)			- 1		TERMINAL.	
4	502-0583	1	Elbow, Pipe - 45 Deg.			- 17	871-0010	2	Nut, Hex - Brass (#10-32)
			(7/16-20 UNF x 1/8" NPT)			18	850-0030	1 :	Washer, Lock - Spring (#10)
5	502-0051	1	Coupling, Pipe (1/8" NPT)			19	526-0205	2	Washer, Flat - Brass (13/64" ID
6	GAUGE, OIL	. PRESSU	RE (Select as Required)					•	x 7/16" OD x 1/16" Thk)
٠.	193-0232	1	Scale Range 0 to 75 PSI			20	853-0008	1	Washer, Lock - ET (#10)
	193-0233	.1	Scale Range 0 to 150 PSI	2.0		21	8560003	1 .	Washer, Lock - EIT (#10)
. 7	GAUGE, TE	MPERATU	RE (Select as Required).			22	815-0203	1	Screw, Machine - Round Head,
	193-0234	1	With 72" Capillary Tube		• /		200		Brass (#10-32 x 7/8")
	193-0235	1	With 84" Capillary Tube				-		<u> </u>
	193-0236	1	With 96" Capillary Tube : 🛒				870-0053	:** . 1	Nut, Hex (#10-32)
	193-0305	1	With 144" Capillary Tube				850-0030	- 1	Washer, Lock - Spring (#10)
8		1	Reducer, Hex (Included with				332-0051	1	Clamp, Loop
			Gauge) (5/8-18 UNF x 1/2" NPT)			26	815-0026	5	Screw, Machine - Truss Head (#10-32 x 3/8")
9	302-0061	1	Ammeter			27 .	870-0053	1	Nut, Hex (#10-32)
10	308-0088	1	Switch, Toggle (DPST)	. `		28 -	850-0030	1	Washer, Lock - Spring (#10)
11	308-0297	1	Switch Push	1.0		29	856-0003	1.	Washer, Lock - EfT (#10)
12	308-0155	1	Switch, Toggle (SPST)	, T		30	301-4009	. 1	Panel, Control - Engine
						31 .	301-3253	1.	Bracket, Mounting - Engine Control



OPTIONAL VERNIER THROTTLE




M-1179

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	812-0075	1	Screw, Machine - Round Head (#8-32 x 1/4")
2	152-0158	1	Swivel
3	800-0005	3	Screw, Cap - Hex Head (1/4-20 x 3/4")
4	850-0040	3	Washer, Lock - Spring (1/4")
5	152-0036	1	Clamp, Holddown - Cable
6	152-0120	1	Throttle Control - Vernier
7	151-0230	1	Bracket, Mounting - Throttle Control




OPTIONAL VOLTAGE REGULATOR FILTER

232-2695



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO	QTY. USED	PART DESCRIPTION
	KIT, FILTER -	VOLTA	GE REGULATOR (Includes	. 7	850-0040	2	Washer, Lock - Spring (1/4")
	Parts Marked *			8	304-0427	4 -	Washer, Centering (1/4")
	232-2694	´ 1	Used on Sets with End Bell	9	304-0292	- 2	Insulator
			Mounted Voltage Regulator	. 10	354-0025	-2	Resistor, Fixed, Wire Wound
	232-2695	1	Used on Sets with Voltage				(10-Ohm, 100 Watt)
	202 2000		Regulator Mounted in Control	11.	813-0098	4	Screw, Machine - Round Head
			Box				(#10-32 x 3/8")
. 1	332-0941	5	*Tie. Cable	12	870-0053	4	Nut, Hex (#10-32)
ż	800-0003	2	*Screw, Cap - Hex Head	13	850-0030	· 4	Washer, Lock - Spring (#10)
-	000 0111		(1/4-20 x 1/2")	14	312-0189	2	Bracket, Mounting - Capacitor
. 3	850-0040	2.	*Washer, Lock - Spring (1/4")	15	312-0188	1	Capacitor, Fixed - 15 MFD,
4		MBĒY (I	Includes all Parts Except				440 VAC
•	as Indicated)			16	232-2210	. 1	Bracket, Mounting
	232-2219	REF	Part of Kit 232-2694	17	232-2693	3	Spacer (Part of 232-2692 Only)
	232-2692	REF	Part of Kit 232-2695	18	TERMINALS	(Select a	s Required)
5	812-0165	2	Screw, Machine - Round Head		332-1279	`8	Insulated 14-16 AWG
. •	0.12 0.00		(1/4-20 x 4-1/2")		332-0529	4	Lug 14-16 AWG
6	862-0001	2	Nut, Hex (1/4-20)	* Parts	included in kit	S.	






XFS1272

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	151-0430	1	Control Unit - Governor (12V)
2	151-0452	1	Actuator - Governor (12V)
3	151-0411	1	Pickup, Magnetic
4	151-0402	1	Potentiometer - Speed Control (5K Ohms)



OPTIONAL LOW COOLANT LEVEL SWITCH



REF.	PART NO.	QTY. USED	PART DESCRIPTION		REF. NO.	PART NO.	QTÝ. USED	PART DESCRIPTION
1	503-0446	4	Clamp, Hose		8	821-0011	2	Screw, Self-locking - Hex
2	503-0707	. 1	Hose, Vinyl (1/4" ID x 12" Lg)		1 - '	Ī		Washer Head (1/4-20 x 7/8")
3	503-0728	1	Hose, Vinyl (1/4" ID x-31" Lg)		9	870-0212	. 2	Nut, Self-locking - Hex
4	130-2053	3	Tube (1/4" OD x 2" Lg)	_	e e			Washer Head (1/4-20)
5	502-0313	1	Elbow, Tube - 90 DEG, Brass		10	193-0329	i t	Switch - Coolant Level
			(1/8" NPT x 1/4" Tube)		11.	502-0809	2 .	Adapter, Tube (Blind Hole
6	505-0151	. 1	Bushing, Reducer - Brass			5 -	900	Fitting) (5/8" OD x 1/4" Tube)
			(1/2" NPT x 1/8" NPT)		12	LEAD, ELECT	TRIĆAL (S	Select as Required)
7	502-0801	. 1	Connector, Tube - Brass			336-8343	1 .	30" Lg
			(1/4" NPT x 1/4" Tube)		-"	336-8344	1.	36" Lg



HARDWARE IDENTIFICATION

Illustrated hardware items are only for identification purposes. All hardware items listed throughout this parts catalog are steel SAE grade five (5) or lower (zinc plated with clear chromate dip) unless parts description indicates differently. All dimensions are in inches.

WASHER TYPES







INTERNAL TOOTH LOCK (IT)



EXTERNAL-INTERNAL TOOTH LOCK (EIT)



COUNTERSUNK EXTERNAL TOOTH









*FLAT


- Flat washer dimensions given are: Inside Diameter (ID), Outside Diameter (OD) and Thickness (Thk).

BOLT AND SCREW TYPES



L - Measure length between these points.





NUT TYPES













FULL HEXAGON

JAM HEXAGON

HEXAGON WASHER

SQUARE

WING

ACORN



Onan Corporation
A subsidiary of
McGraw-Edison Company
1400 73rd Avenue N.E.
Power applies, Minnesota 55432
Generation

612 574 5000 Telex 29 0476 TWX 910 576/2833